

Air-Cooled Scroll Compressor Chiller

AGZ025D – AGZ190D (Rev 0A) 25 to 190 Tons

50 - 60-Hertz, R-410A

Software Version 251699201



Table of Contents

Introduction.....	3	Unit Problem Alarms.....	37
Operating/Standby Limits	9	Unit Warning Alarms.....	38
Pressure Drop Curves.....	9	Circuit Fault Alarms	38
Minimum Allowable Flow Rates	9	Circuit Events.....	40
Pressure Drop Curves	10	Circuit Warning Alarms.....	41
MicroTech® III Controller	13	Events	41
Controller Section Table of Contents.....	13	Unit Events.....	42
Security.....	20	Circuit Events.....	42
Unit Functions	20	Clearing Alarms	Error! Bookmark not defined.
Definitions	20	Using the Controller.....	44
Unit Enable	21	Navigating.....	45
Unit Mode Selection.....	22	Menus.....	47
Unit States.....	22	Optional Low Ambient Fan VFD ..	60
Power Up Start Delay	23	VFD Interface (HMI)	61
Ice Mode Start Delay	23	Recommended Periodic Inspection	65
Unit Status	23	Optional BAS Interface	65
Evaporator Pump Control.....	24	Startup.....	66
LWT Target.....	25	Operation	68
Unit Capacity Control.....	26	Unit Maintenance.....	73
Unit Capacity Overrides	27	Planned Maintenance Schedule.....	74
Circuit Functions.....	29	Service	75
Definitions	29	R-410A.....	75
Circuit Control Logic.....	29	Refrigerant Charging.....	76
Pumpdown Procedure.....	31	Evaporator.....	78
Low Ambient Starts	31	AGZ-D Troubleshooting Chart.....	79
Circuit Status	31	Warranty Statement	Error! Bookmark not defined.
Compressor Control.....	31		
Condenser Fan Control	32		
EXV Control.....	34		
Liquid Line Solenoid Valve	35		
Hot Gas Bypass Solenoid Valve	35		
Capacity Overrides – Limits of Operation .	35		
Alarms.....	35		
Unit Fault Alarms.....	35		

Cover picture: AGZ 190D



Our facility is ISO Certified

©2014 Daikin Applied. Illustrations and data cover the Daikin Applied product at the time of publication and we reserve the right to make changes in design and construction at anytime without notice.

Introduction

General Description

NOTE: Vintage changes; this manual covers Revision 0A to the original AGZD version “00”. The units are very close in appearance but can be differentiated by their nameplate.

Version 00 name plate is AGZ.....E10
Revision 0A nameplate is AGZ.....E11

Daikin Applied air-cooled global water chillers are complete, self-contained automatic refrigerating units. Every unit is completely assembled, factory wired, charged, and tested (except remote evaporator option). Each unit consists of twin air-cooled condensers with integral subcooler sections, two tandem or triple scroll compressors, brazed-plate or replaceable tube, dual circuit shell-and-tube evaporator, and complete refrigerant piping. Liquid line components include manual liquid line shutoff valves, sight-glass/moisture

indicators, solenoid valves, and thermal expansion valves.


Other features include compressor crankcase heaters, an evaporator heater for chilled water freeze protection, , automatic compressor lead-lag to alternate the compressor starting sequence, and sequenced starting of compressors.

The electrical control center includes all equipment protection and operating controls necessary for dependable automatic operation.

This manual covers units with Software Version 251699201 which must be used with firmware version 9.XX.

Installation, information is in IM 1165 (or current, latest dash number) manual.

Nomenclature



Hazard Identification Information

⚠ DANGER

Dangers indicate a hazardous situation which will result in death or serious injury if not avoided.

⚠ WARNING

Warnings indicate potentially hazardous situations, which can result in property damage, severe personal injury, or death if not avoided.

⚠ CAUTION

Cautions indicate potentially hazardous situations, which can result in personal injury or equipment damage if not avoided.

Ambient Air Temperature Limitations

Standard/High Ambient Panels

The maximum operating ambient temperature for standard units is 104°F (40°C). AGZ-D units for high ambient operation (105°F to 125°F maximum) require the addition of the High Ambient Control Panel Option, which includes the addition of a small fan with a filter in the air intake to cool the control panel.

All units with the optional variable frequency drive (VFD) low ambient fan control automatically include the High Ambient Control Panel Option. Operation of the VFD generates a quantity of panel heat best removed by use of a control panel fan.

Water Flow Limitations

The evaporator flow rates and pressure drops shown on page 11 are for full load design purposes in order to maintain proper unit control. The maximum flow rate and pressure drop are based on a 6 degree temperature drop. Avoid higher flow rates with resulting lower temperature drops to prevent potential control problems resulting from very small control bands and limited start up/shut off temperature changes.

The minimum flow and pressure drop is dependent on whether constant or variable flow is employed in the chilled water system. See 9 for details. Evaporator flow rates below the minimum values can result in laminar flow causing freeze-up problems, scaling and poor control. Flow rates above the maximum values will result in unacceptable pressure drops and can cause excessive erosion, potentially leading to failure.

Variable Speed Pumping

Variable water flow involves changing the water flow through the evaporator as the load changes. Daikin Applied chillers are designed for this duty provided that the rate of change in

water flow is slow and the minimum and maximum flow rates for the vessel are not exceeded.

The recommended maximum change in water flow is 10 percent of the change per minute.

When units are operated with flow rates less than nominal (see

Table 8 on page 11), the “Evap Delta T” setpoint must be changed proportionally to match the minimum operating flow rate. The “Delta T” setting should be increased by the same percentage as the flow reduction is from the nominal rating in order to prevent short cycling. This will require reevaluation of “Cool LWT”, “Startup Delta T”, and “Stop Delta T” settings as well

System Water Volume Considerations

All chilled water systems need adequate time to recognize a load change, respond to that load change and stabilize without undesirable short cycling of the compressors or loss of temperature control. In air conditioning systems, the potential for short cycling usually exists when the building load falls below the minimum chiller plant capacity or on close-coupled systems with very small water volumes.

Some of the things the designer should consider when looking at water volume are the minimum cooling load, the minimum chiller plant capacity during the low load period and the desired cycle time for the compressors.

Assuming that there are no sudden load changes and that the chiller plant has reasonable turndown, a rule of thumb of “gallons of water volume equal to two to three times the chilled water gpm flow rate” is often used.

A properly designed storage tank should be added if the system components do not provide sufficient water volume.

Glycol Solutions

The use of a glycol/water mixture in the evaporator to prevent freezing reduces system capacity and efficiency, as well as increase pressure drop. The system capacity, required glycol solution flow rate, and pressure drop with glycol may be calculated using Table 1.

1. **Capacity** – Multiply the capacity based on water by the *Capacity* correction factor from Table 2 through Table 5.
2. **Flow** – Multiply the water evaporator flow by the *Flow* correction factor from Table 2 through Table 5 to determine the increased evaporator flow due to glycol.

If the flow is unknown, it can be calculated from the following equation

3. **Pressure drop** -- Multiply the water pressure drop from page 9 by *Pressure Drop* correction factor from Table 2 through Table 5. High concentrations of propylene glycol at low temperatures can cause unacceptably high pressure drops.
4. **Power** -- Multiply the water system power by *Power* correction factor from Table 2 - Table 5.

Test coolant with a clean, accurate glycol solution hydrometer (similar to that found in service stations) to determine the freezing point. Obtain percent glycol from the freezing point tables below. It is recommended that a minimum of 25% solution by weight be used for protection against corrosion or that additional compatible inhibitors be added.

Concentrations above 35 % do not provide any additional burst protection and should be carefully considered before using.

Table 1, Flow/Tons/Delta-T Relationship

Glycol Flow (gpm)	$\frac{24 \times \text{Tons Capacity (glycol)}}{\text{Delta } T} \times \text{Flow Correction Factor}$
Glycol Flow (l/s)	$\frac{\text{kW Capacity}}{4.18 \times \text{Delta } - T} \times \text{Flow Correction Factor}$

⚠ WARNING

Do not use an automotive grade antifreeze. Industrial grade glycols must be used. Automotive antifreeze contains inhibitors which will cause plating on the copper tubes within the chiller evaporator. The type and handling of glycol used must be consistent with local codes

Table 2, Ethylene Glycol Factors for Models AGZ 025D to 130D

% E.G.	Freeze Point		Capacity	Power	Flow	PD
	°F	°C				
10	26	-3.3	0.998	0.998	1.036	1.097
20	18	-7.8	0.993	0.997	1.060	1.226
30	7	-13.9	0.987	0.995	1.092	1.369
40	-7	-21.7	0.980	0.992	1.132	1.557
50	-28	-33.3	0.973	0.991	1.182	1.791

Table 3, Propylene Glycol Factors for Models AGZ 025D to 130D

% P.G.	Freeze Point		Capacity	Power	Flow	PD
	°F	°C				
10	26	-3.3	0.995	0.997	1.016	1.100
20	19	-7.2	0.987	0.995	1.032	1.211
30	9	-12.8	0.978	0.992	1.057	1.380
40	-5	-20.6	0.964	0.987	1.092	1.703
50	-27	-32.8	0.952	0.983	1.140	2.251

Table 4, Ethylene Glycol Factors for Models AGZ 140D to 190D

% E.G.	Freeze Point		Capacity	Power	Flow	PD
	°F	°C				
10	26	-3.3	0.994	0.998	1.038	1.101
20	18	-7.8	0.982	0.995	1.063	1.224
30	7	-13.9	0.970	0.992	1.095	1.358
40	-7	-21.7	0.955	0.987	1.134	1.536
50	-28	-33.3	0.939	0.983	1.184	1.755

Table 5, Propylene Glycol Factors for Models AGZ 140D to 190D

% P.G.	Freeze Point		Capacity	Power	Flow	PD
	°F	°C				
10	26	-3.3	0.988	0.996	1.019	1.097
20	19	-7.2	0.972	0.992	1.035	1.201
30	9	-12.8	0.951	0.987	1.059	1.351
40	-5	-20.6	0.926	0.979	1.095	1.598
50	-27	-32.8	0.906	0.974	1.142	2.039

Altitude Correction Factors

Performance tables are based at sea level. Elevations other than sea level affect the performance of the unit. The decreased air density will reduce condenser capacity consequently reducing the unit's performance. For performance at elevations other than sea level, refer to Table 6 and Table 7.

Evaporator Temperature Drop Factors

Performance tables are based on a 10°F (5°C) temperature drop through the evaporator. Adjustment factors for applications with temperature ranges from 6°F to 16°F (3.3°C to 8.9°C) are in Table 6 and Table 7.

Temperature drops outside this 6°F to 16°F (3.3°C to 8.9°C) range can affect the control system's capability to maintain acceptable control and are not recommended.

The maximum water temperature that can be circulated through the evaporator in a non-operating mode is 100°F (37.8°C).

Fouling Factor

Performance tables are based on water with a fouling factor of:

$0.0001 \text{ft}^2 \times \text{hr} \times ^\circ\text{F} / \text{BTU}$ or $(0.0176 \text{m}^2 \times ^\circ\text{C} / \text{kW})$
per ARI 550/590-98.

As fouling is increased, performance decreases. For performance at other than 0.0001 (0.0176) fouling factor, refer to Table 6 or Table 7.

Foreign matter in the chilled water system will adversely affect the heat transfer capability of the evaporator and could increase the pressure drop and reduce the water flow. Maintain proper water treatment to provide optimum unit operation.

Table 6, Capacity and Power Derates, Models AGZ 025D to 130D

Altitude	Chilled Water Delta T		Fouling Factor							
			0.0001 (0.0176)		0.00025 (0.044)		0.00075 (0.132)		0.00175 (0.308)	
	°F	°C	Cap.	Power	Cap.	Power	Cap.	Power	Cap.	Power
Sea Level	6	3.3	0.978	0.993	0.975	0.991	0.963	0.987	0.940	0.980
	8	4.4	0.989	0.996	0.986	0.994	0.973	0.990	0.950	0.983
	10	5.6	1.000	1.000	0.996	0.999	0.984	0.994	0.961	0.987
	12	6.7	1.009	1.003	1.005	1.001	0.993	0.997	0.969	0.990
	14	7.7	1.018	1.004	1.014	1.003	1.002	0.999	0.978	0.991
	16	8.9	1.025	1.007	1.021	1.006	1.009	1.001	0.985	0.994
2000 feet	6	3.3	0.977	1.001	0.973	1.000	0.961	0.996	0.938	0.989
	8	4.4	0.987	1.006	0.984	1.004	0.971	1.000	0.948	0.993
	10	5.6	0.998	1.009	0.995	1.007	0.982	1.003	0.959	0.996
	12	6.7	1.007	1.011	1.004	1.010	0.991	1.006	0.967	0.998
	14	7.7	1.014	1.014	1.011	1.013	0.998	1.009	0.974	1.001
	16	8.9	1.022	1.016	1.018	1.014	1.005	1.010	0.981	1.003
4000 feet	6	3.3	0.973	1.011	0.970	1.010	0.957	1.006	0.935	0.998
	8	4.4	0.984	1.014	0.980	1.013	0.968	1.009	0.945	1.001
	10	5.6	0.995	1.019	0.991	1.017	0.979	1.013	0.955	1.005
	12	6.7	1.004	1.021	1.000	1.020	0.987	1.016	0.964	1.008
	14	7.7	1.011	1.024	1.007	1.023	0.994	1.018	0.971	1.011
	16	8.9	1.018	1.027	1.014	1.026	1.002	1.021	0.978	1.014
6000 feet	6	3.3	0.969	1.021	0.966	1.020	0.954	1.016	0.931	1.008
	8	4.4	0.980	1.026	0.977	1.024	0.964	1.020	0.942	1.013
	10	5.6	0.989	1.029	0.986	1.027	0.973	1.023	0.950	1.015
	12	6.7	0.998	1.033	0.995	1.031	0.982	1.027	0.959	1.020
	14	7.7	1.007	1.036	1.004	1.034	0.991	1.030	0.967	1.022
	16	8.9	1.014	1.037	1.011	1.036	0.998	1.031	0.974	1.024

Table 7, Capacity and Power Derates, Models AGZ 140D to 190D

Altitude	Chilled Water Delta T		Fouling Factor							
			0.0001 (0.0176)		0.00025 (0.044)		0.00075 (0.132)		0.00175 (0.308)	
	°F	°C	Cap.	Power	Cap.	Power	Cap.	Power	Cap.	Power
Sea Level	6	3.3	0.990	0.997	0.976	0.994	0.937	0.983	0.868	0.964
	8	4.4	0.994	0.998	0.981	0.995	0.942	0.984	0.872	0.965
	10	5.6	1.000	1.000	0.987	0.996	0.947	0.986	0.877	0.967
	12	6.7	1.005	1.001	0.991	0.997	0.951	0.986	0.881	0.968
	14	7.7	1.009	1.002	0.995	0.998	0.955	0.987	0.884	0.968
	16	8.9	1.013	1.004	1.000	1.000	0.960	0.989	0.889	0.970
2000 feet	6	3.3	0.987	1.005	0.974	1.002	0.934	0.991	0.865	0.972
	8	4.4	0.992	1.006	0.979	1.003	0.940	0.992	0.870	0.973
	10	5.6	0.997	1.008	0.984	1.004	0.944	0.994	0.875	0.975
	12	6.7	1.002	1.009	0.989	1.005	0.949	0.994	0.879	0.975
	14	7.7	1.007	1.011	0.993	1.007	0.953	0.996	0.883	0.977
	16	8.9	1.011	1.012	0.998	1.008	0.958	0.997	0.887	0.978
4000 feet	6	3.3	0.985	1.014	0.972	1.010	0.933	0.999	0.864	0.980
	8	4.4	0.991	1.015	0.977	1.012	0.938	1.001	0.869	0.981
	10	5.6	0.995	1.016	0.982	1.013	0.943	1.002	0.873	0.982
	12	6.7	1.000	1.018	0.987	1.014	0.947	1.003	0.877	0.984
	14	6.8	1.005	1.019	0.991	1.015	0.951	1.004	0.881	0.985
	16	8.9	1.009	1.021	0.995	1.017	0.955	1.006	0.884	0.987
6000 feet	6	3.3	0.982	1.023	0.969	1.020	0.930	1.009	0.861	0.989
	8	4.4	0.988	1.025	0.975	1.022	0.935	1.010	0.866	0.991
	10	5.6	0.992	1.026	0.979	1.022	0.940	1.011	0.870	0.992
	12	6.7	0.997	1.028	0.984	1.024	0.944	1.013	0.875	0.994
	14	7.7	1.002	1.029	0.989	1.025	0.949	1.014	0.879	0.995
	16	8.9	1.006	1.031	0.992	1.027	0.952	1.016	0.882	0.996
8000 feet	6	3.3	0.979	1.034	0.966	1.031	0.927	1.019	0.859	1.000
	8	4.4	0.984	1.036	0.971	1.032	0.932	1.021	0.863	1.002
	10	5.6	0.990	1.037	0.976	1.033	0.937	1.022	0.868	1.002
	12	6.7	0.993	1.039	0.980	1.035	0.941	1.024	0.871	1.004
	14	7.7	0.998	1.041	0.985	1.037	0.945	1.026	0.875	1.006
	16	8.9	1.003	1.041	0.990	1.038	0.950	1.026	0.879	1.007

Evaporator Freeze Protection

Evaporator freeze-up can be a concern in the application of air-cooled water chillers. To protect against freeze-up, insulation and an electric heater cable are furnished with the unit. This protects the evaporator down to -20°F (-29°C) ambient air temperature. Although the evaporator is equipped with freeze protection, it does not protect water piping external to the unit or the evaporator itself if there is a power failure or heater cable burnout. Consider the following recommendations for additional protection.

1. If the unit will not be operated during the winter, drain evaporator and chilled water piping and flush with glycol. Drain and

vent connections are provided on the evaporator to ease draining.

2. Add a glycol solution to the chilled water system to provide freeze protection. Freeze point should be approximately ten degrees below minimum design ambient temperature.
3. The addition of thermostatically controlled heat and insulation to exposed piping.
4. Continuous circulation of water through the chilled water piping and evaporator.

The evaporator heater cable is factory wired to the 115-volt circuit in the control box. This power should be supplied from a separate source, but it can be supplied from the control circuit. Operation of the heater cable is

automatic through the ambient sensing thermostat that energizes the evaporator heater cable for protection against freeze-up. Unless

the evaporator is drained in the winter, the disconnect switch to the evaporator heater must not be open.

Operating/Standby Limits

- Maximum standby ambient air temperature, 130° F (55° C)
- Maximum operating ambient air temperature 105° F (40.6° C)
- Minimum operating ambient temperature (standard), 35° F (2° C)
- Minimum operating ambient temperature (with optional low-ambient control), -10° F (-23.3°C)
- Leaving chilled water temperature, 40°F to 60°F (4.4° C to 15.6° C)
- Leaving chilled fluid temperatures (with anti-freeze), 15° F to 60° F (-9.4°C to 15.6°C)
- Chilled water Delta-T range, 6 degrees F to 16 degrees F (3.3 degrees C to 8.9 degrees C)
- Part load minimum flow for variable flow systems, varies with unit size; see Table 8, page 11.
- Maximum operating inlet fluid temperature, 76° F (24° C)
- Maximum non-operating inlet fluid temperature, 100°F (38° C).

Pressure Drop Curves

Minimum Allowable Flow Rates

In order to maximize energy savings from variable flow systems, the AGZD chiller employs different control strategies for constant-flow chilled water systems as compared to variable-flow systems.

A chiller controller setpoint selects the proper controller operation. The software setting of Variable Evap. Flow equals YES or NO is located just below the “Full Cap D-T” setting screen.

The Full Cap D-T setting will continue to allow settings from 6 to 16 F Delta-T for full load operation.

Constant-Chilled Water Flow Systems

The minimum allowable flow is determined by the chiller model. Operating with flows below these values can cause unstable operation.

Variable-Chilled Water Flow Systems

For models AGZ 025D through AGZ 130D the part load flow rate in a variable chilled water flow system is 40% of nominal catalog *full load* flow (rated catalog tons x 2.4 = full load GPM). These minimum allowable flows are calculated to allow the chilled water flow to decrease progressively as the unit capacity decreases, but is restricted to 40% of rated full load flow.

The larger AGZ 140D to 190D units have shell and tube evaporators and will operate at the same minimum flow rate as for constant flow (62.5% of nominal catalog full load flow rate.)

When “Variable Evap Flow” is selected as YES – the unit software will increase the control band progressively as the unit capacity steps to the lower stages of 75%, 50% and 25% load for the four compressors. This prevents short cycling and allows for decreasing minimum water flow as the unit capacity decreases. The 6 compressor units will have a similar operation but with software calculations based on 6 capacity steps.

Refer to Table 8 on page 11 for the allowable reduced minimum flows.

Pressure Drop Curves

The pressure drop for any given unit is the same regardless of constant or variable flow. Only the lower cutoff point for minimum flow will change.

Table 8 on page 11 contains the evaporator reference letter and the minimum and maximum flows allowed for each unit. Occasionally the same evaporator is used on multiple units resulting in overlapping lines.

The nominal and maximum flow and pressure drop are the same for a given unit size regardless of having fixed or variable flow.

The curves are based on water use only. Use glycol adjustment factors located in the catalog Performance Section as required.

Figure 1, Evaporator Pressure Drops. See following page for curve cross-reference

See following page for curve cross-reference and min/max flow rates.





Table 8, Curve Cross-Reference, Min/Nominal/Max Flows

AGZ Model	Curve Ref.	Variable Flow System Only				Fixed Flow System Only				Fixed and Variable Flow Systems							
		Minimum Flow Rate				Minimum Flow Rate				Nominal Flow Rate				Maximum Flow Rate			
		IP		SI		IP		SI		IP		SI		IP		SI	
		GPM	DP ft.	lps	DP kpa	GPM	DP ft.	lps	DP kpa	GPM	DP ft.	lps	DP kpa	GPM	DP ft.	lps	DP kpa
025D	A	26.4	1.6	1.7	4.8	41.3	3.8	2.6	11.5	66.0	9.4	4.2	28.1	110.0	24.8	6.9	74.1
030D	B	30.3	2.2	1.9	6.4	47.4	5.0	3.0	15.0	75.8	12.3	4.8	36.7	126.3	32.4	8.0	96.8
035D	C	33.5	2.4	2.1	7.1	52.4	5.4	3.3	16.1	83.8	13.6	5.3	40.6	139.7	35.9	8.8	107.3
040D	D	36.4	2.4	2.3	7.1	56.9	5.4	3.6	16.1	91.0	13.5	5.7	40.4	151.7	35.6	9.6	106.4
045D	E	40.9	2.3	2.6	6.9	63.9	5.3	4.0	15.8	102.2	13.2	6.4	39.5	170.3	34.8	10.7	104.0
050D	F	46.2	2.6	2.9	7.8	72.1	6.1	4.6	18.2	115.4	14.9	7.3	44.5	192.3	39.3	12.1	117.5
055D	G	49.5	2.3	3.1	7.0	77.4	5.4	4.9	16.3	123.8	13.3	7.8	39.7	206.3	35.1	13.0	104.9
060D	H	53.8	2.2	3.4	6.6	84.1	5.1	5.3	15.3	134.6	12.5	8.5	37.3	224.3	33.0	14.2	98.6
065D	I	55.8	1.9	3.5	5.8	87.1	4.5	5.5	13.4	139.4	11.0	8.8	32.8	232.3	29.0	14.7	86.7
070D	J	61.5	2.3	3.9	7.0	96.1	5.4	6.1	16.3	153.8	13.3	9.7	39.7	256.3	35.1	16.2	104.9
075D	J	70.2	2.3	4.4	6.8	109.6	5.3	6.9	15.8	175.4	12.9	11.1	38.5	292.3	34.0	18.4	101.6
080D	L	77.8	2.2	4.9	6.7	121.6	5.2	7.7	15.6	194.6	12.8	12.3	38.2	324.3	33.8	20.5	101.0
090D	M	85.6	2.4	5.4	7.1	133.8	5.4	8.4	16.1	214.1	13.5	13.5	40.4	356.8	35.1	22.5	104.9
100D	N	95.8	2.2	6.0	6.6	149.7	5.2	9.4	15.4	239.5	12.6	15.1	37.6	399.2	33.3	25.2	99.5
110D	O	101.8	2.3	6.4	6.8	159.1	5.3	10.0	15.9	254.6	13.0	16.1	38.8	424.3	34.3	26.8	102.5
125D	P	112.4	2.3	7.1	6.9	175.6	5.4	11.1	16.1	281.0	13.2	17.7	39.7	468.3	34.8	29.5	104.0
130D	Q	124.3	2.4	7.8	7.2	194.3	5.5	12.3	16.5	310.8	13.5	19.6	40.4	518.0	35.6	32.7	106.4
140D	R	204.3	4.8	12.9	14.4	204.3	4.8	12.9	14.4	326.9	11.8	20.6	35.2	544.8	31.1	34.4	93.0
160D	S	229.9	5.9	14.5	17.7	229.9	5.9	14.5	17.7	367.9	14.5	23.2	43.3	613.2	38.3	38.7	114.5
180D	T	258.3	7.4	16.3	22.0	258.3	7.4	16.3	22.0	413.3	18.0	26.1	53.7	688.8	47.5	43.5	142.0
190D	U	270.1	9.0	17.0	26.9	270.1	9.0	17.0	26.9	432.2	22.0	27.3	65.7	720.3	58.1	45.4	173.7

Figure 2, Typical Field Control Wiring



MicroTech® III Controller

Controller Section Table of Contents

Overview.....	14
Controller Inputs and Outputs	14
Setpoints	16
Security	20
Unit Control Functions	20
Unit Enable	21
Unit Mode Selection	22
Unit States.....	22
Start Delays.....	23
Evaporator Pump Control	24
Leaving Water Temperature (LWT) Reset/Target	25
Unit Capacity Control.....	26
Unit Capacity Overrides.....	27
Circuit Control Functions	29
Circuit Control Logic.....	29
Pumpdown Procedure	31
Compressor Control.....	31
Condenser Fan Control.....	32
EXV Control.....	34
Liquid Line Solenoid	35
Hot Gas Bypass Solenoid	35
Alarms.....	35
Events.....	41
Clearing Alarms	43
Using the Controller.....	44

Overview

The MicroTech® III controller's state-of-the-art design not only permits the chiller to run more efficiently, but also can simplify troubleshooting if a system failure occurs. Every MicroTech III controller is programmed and tested prior to shipment to facilitate start-up.

Operator-friendly

The MicroTech III controller menu structure is separated into three distinct categories that provide the operator or service technician with a full description of :

1. current unit status
2. control parameters
3. alarms. Security protection prevents unauthorized changing of the setpoints and control parameters.

MicroTech III control continuously performs self-diagnostic checks, monitoring system temperatures, pressures and protection devices, and will automatically shut down a compressor or the entire unit should a fault occur. The cause of the shutdown will be retained in memory and can be easily displayed in plain English for operator review. The MicroTech III chiller controller will also retain and display the date/time the fault occurred. In addition to displaying alarm diagnostics, the MicroTech III chiller controller also provides the operator with a warning of limit (pre-alarm) conditions.

Controller Inputs and Outputs

Main Controller

Table 9, Analog Inputs

#	Description	Type	Expected Range
AI1	Evaporator EWT	NTC 10k	340 to 300k Ω
AI2	Evaporator LWT	NTC 10k	340 to 300k Ω
AI3	Outside Ambient Temperature	NTC 10k	340 to 300k Ω
X1	Demand Limit	4-20 mA	1 to 23 mA
X4	LWT Reset	4-20 mA	1 to 23 mA

Table 10, Analog Outputs

#	Description	Output Type	Range
X5	Circuit 1 Fan VFD Speed	Voltage	0 to 10 volts
X6	Circuit 2 Fan VFD Speed	Voltage	0 to 10 volts

Table 11, Digital Inputs

	Description	Signal Off	Signal On
DI1	External Alarm/Event	External Fault	No External Fault
DI2	Evaporator Flow Switch	No Flow	Flow
DI3	Double Set Point/ Mode Switch	See sections on Unit Mode Selection and LWT Target	
DI4	Remote Switch	Remote Disable	Remote Enable
DI5	Unit Switch	Unit Disable	Unit Enable

Table 12, Digital Outputs

	Description	Output Off	Output On
DO1	Evaporator Water Pump 1	Pump Off	Pump On
DO2	Alarm Indicator	Alarm Not Active	Alarm Active
DO3	Circuit 1 Fan Output 1	Fan(s) Off	Fan(s) On
DO4	Circuit 1 Fan Output 2	Fan(s) Off	Fan(s) On
DO5	Circuit 1 Fan Output 3	Fan(s) Off	Fan(s) On
DO6	Circuit 1 Fan Output 4	Fan(s) Off	Fan(s) On
DO7	Circuit 2 Fan Output 1	Fan(s) Off	Fan(s) On
DO8	Circuit 2 Fan Output 2	Fan(s) Off	Fan(s) On
DO9	Circuit 2 Fan Output 3	Fan(s) Off	Fan(s) On
DO10	Circuit 2 Fan Output 4	Fan(s) Off	Fan(s) On

Compressor Module 1

Analog Inputs

	Description	Signal Type	Expected Range
X1	Circuit 1 Suction Temperature	NTC 10k	340 to 300k Ω
X2	Circuit 1 Evaporator Pressure	Voltage	0.4 to 4.6 volts
X4	Circuit 1 Condenser Pressure	Voltage	0.4 to 4.6 volts

Digital Inputs

	Description	Signal Off	Signal On
X6	Circuit 1 Switch	Circuit Disable	Circuit Enable
X7	Circuit 1 MHP Switch	Fault	No fault
X8	Circuit 1 Motor Protection	Fault	No fault
DI1	Circuit 1 (or Unit) PVM/GFP	Fault	No fault

Digital Outputs

	Description	Output Off	Output On
DO1	Compressor #1	Compressor Off	Compressor On
DO2	Compressor #3	Compressor Off	Compressor On
DO3	Compressor #5	Compressor Off	Compressor On
DO4	Evaporator Water Pump 2	Pump Off	Pump On
DO5	Circuit 1 Hot Gas Bypass SV	Solenoid Closed	Solenoid Open
DO6	Circuit 1 Liquid Line SV	Solenoid Closed	Solenoid Open

Compressor Module 2

Analog Inputs

	Description	Signal Type	Expected Range
X1	Circuit 2 Suction Temperature	NTC 10k	340 to 300k Ω
X2	Circuit 2 Evaporator Pressure	Voltage	0.4 to 4.6 volts
X4	Circuit 2 Condenser Pressure	Voltage	0.4 to 4.6 volts

Digital Inputs

	Description	Signal Off	Signal On
X6	Circuit 2 Switch	Circuit Disable	Circuit Enable
X7	Circuit 2 MHP Switch	Fault	No fault
X8	Circuit 2 Motor Protection	Fault	No fault
DI1	Circuit 2 PVM/GFP	Fault	No fault

Note: The Motor Protection and MHP input signal are wired in series. If Motor Protection input is open, MHP Switch input will also be open.

Digital Outputs

	Description	Output Off	Output On
DO1	Compressor #2	Compressor Off	Compressor On
DO2	Compressor #4	Compressor Off	Compressor On
DO3	Compressor #6	Compressor Off	Compressor On
DO5	Circuit 2 Hot Gas Bypass SV	Solenoid Closed	Solenoid Open
DO6	Circuit 2 Liquid Line SV	Solenoid Closed	Solenoid Open

EXV Module 1 and 2

These modules will be used only when the expansion valve type is electronic.

Digital Outputs

	Description	Output Off	Output On
DO1	Circuit 1 Fan Output 5	Fan(s) Off	Fan(s) On

Stepper Motor Output

	Description
M1+, M1-	EXV Stepper Coil 1
M2+, M2-	EXV Stepper Coil 2

Sensor Information

Temperature

All temperature sensors will be Daikin Applied part number 1934146.

Pressure

Pressure inputs will be read using 0 to 5 volt ratiometric sensors. Nominal voltage range will be 0.5 to 4.5 volts.

Pressure on the low side will be measured using Daikin Applied part number 331764501.

Pressure on the high side will be measured using Daikin Applied part number 331764601.

Actuator Information

- The electronic expansion valves used are Daikin Applied part number 33038620X. These valves are Sporlan supplied and all use the same bipolar stepper motor.

Setpoints

Setpoints are stored in permanent memory.

SetPoint Tables

Setpoints are initially set to the values in the **Default** column, and can be adjusted to any value in the **Range** column.

Unit Level Setpoints:

Description	Default	Range
Mode/Enabling		
Unit Enable	Enable	Disable, Enable
Network Unit Enable	Disable	Disable, Enable
Control source	Local	Local, Network
Available Modes	Cool	Cool, Cool w/Glycol, Cool/Ice w/Glycol Ice, Test
Network Mode Command	Cool	Cool, Ice
Staging and Capacity Control		
Cool LWT 1	7°C (44.6°F)	See Auto Adjusted Ranges, page 19
Cool LWT 2	7°C (44.6°F)	See Auto Adjusted Ranges, page 19
Ice LWT	4.4°C (39.9°F)	-9.5 to 4.4 °C (14.9 to 39.9 °F)
Network Cool Set Point	7°C (44.6°F)	See Auto Adjusted Ranges, page 19
Network Ice Set Point	4.4°C (39.9°F)	-9.5 to 4.4 °C (14.9 to 39.9 °F)
Startup Delta T	5.6°C (10.1°F)	0.6 to 8.3 °C (1.1 to 14.9 °F)
Shut Down Delta T	0.3°C (0.5°F)	0.3 to 1.7 °C (0.5 to 3.1 °F)
Max Pulldown	0.6°C/min (1.1°F/min)	0.1 to 2.7 °C/min (0.2 to 4.9 °F/min)
Nominal Evap Delta T	5.6 °C (10.1°F)	3.3 to 8.9 °C (5.9 to 16 °F)
Demand Limit Enable	Off	Off, On
Network Capacity Limit	100%	0 to 100%
LWT Reset Enable	Off	Off, On
Configuration		
Power Input	Single Point	Single Point, Multi Point
Evap Control	#1 Only	#1 Only, #2 Only, Auto, #1 Primary, #2 Primary
Number of Compressors	4	4,6
Expansion Valve Type	Thermal	Thermal, Electronic
Fan VFD enable	No	No, Yes
Number of fans	4	4,6,8,10,12,14
Timers		
Evap Recirc Timer	30	15 to 300 seconds
Stage Up Delay	240 sec	120 to 480 sec
Stage Down Delay	30 sec	20 to 60 sec
Stage Delay Clear	No	No, Yes
Start-start timer	15 min	10-60 minutes
Stop-start timer	5 min	3-20 minutes
Clear Cycle Timers	No	No, yes
Ice Time Delay	12	1-23 hours
Clear Ice Timer	No	No, Yes
Sensor Offsets		
Evap LWT sensor offset	0°C (0°F)	-5.0 to 5.0 °C (-9.0 to 9.0 °F)
Evap EWT sensor offset	0°C (0°F)	-5.0 to 5.0 °C (-9.0 to 9.0 °F)
OAT sensor offset	0°C (0°F)	-5.0 to 5.0 °C (-9.0 to 9.0 °F)
Alarm Settings		
Low Evap Pressure Unload	689.5 KPA(100 PSI)	See section 5.1.1

Low Evap Pressure Hold	696.4 KPA(101 PSI)	See section 5.1.1
High Condenser Pressure	4240 KPA(615 PSI)	3310 to 4275 KPA (480 to 620 PSI)

Continued next page.

Description	Default	Range
High Condenser Pressure Unload	4137 KPA(600 PSI)	3241 to 4137 KPA (470 to 600 PSI)
Evaporator Flow Proof	5 sec	5 to 15 sec
Recirculate Timeout	3 min	1 to 10 min
Evaporator Water Freeze	2.2°C (36°F)	See Auto Adjusted Ranges, page 19
Low OAT Start Time	165 sec	150 to 240 sec
External Alarm Configuration	Event	Event, Alarm
Clear Alarms	Off	Off, On
Network Clear Alarms	Off	Off, On

Circuit Setpoints (exist individually for each circuit):

Description	Default	Range
Mode/Enabling		
Circuit mode	Enable	Disable, Enable, Test
Compressor 1 Enable	Enable	Enable, Disable
Compressor 2 Enable	Enable	Enable, Disable
Compressor 3 Enable	Enable	Enable, Disable
Network Compressor 1 Enable	Enable	Enable, Disable
Network Compressor 2 Enable	Enable	Enable, Disable
Network Compressor 3 Enable	Enable	Enable, Disable
EXV control	Auto	Auto, manual
EXV position	See Special Setpoints, page 19	0% to 100%
Suction SH Target	5.56°C (10°F)	4.44 to 6.67 °C (8 to 12 °F)
Max Evap Pressure	1076 KPA(156.1 PSI)	979 to 1172 KPA (142 to 170 PSI)
Condenser		
Condenser Target 100%	37.8°C (100°F)	32.22 to 48.9 °C (90 to 120 °F)
Condenser Target 67%	32.2°C (90°F)	32.22 to 48.9 °C (90 to 120 °F)
Condenser Target 50%	32.2°C (90°F)	29.44 to 43.3 °C (85 to 110 °F)
Condenser Target 33%	29.4°C (85°F)	29.44 to 43.3 °C (85 to 110 °F)
VFD Max Speed	100%	90 to 110%
VFD Min Speed	25%	25 to 60%
Fan Stage Up Deadband 1	8.33°C (15°F)	8.33 to 13.89 °C (15 to 25 °F)
Fan Stage Up Deadband 2	5.56°C (10°F)	5.56 to 8.33 °C (10 to 15 °F)
Fan Stage Up Deadband 3	5.56°C (10°F)	5.56 to 8.33 °C (10 to 15 °F)
Fan Stage Up Deadband 4	5.56°C (10°F)	5.56 to 8.33 °C (10 to 15 °F)
Fan Stage Down Deadband 1	11.11°C (20°F)	8.33 to 11.11 °C (15 to 20 °F)
Fan Stage Down Deadband 2	11.11°C (20°F)	8.33 to 11.11 °C (15 to 20 °F)
Fan Stage Down Deadband 3	8.33 °C (15 °F)	5.56 to 8.33 °C (10 to 15 °F)
Fan Stage Down Deadband 4	5.56 °C (10 °F)	3.33 to 5.56 °C (6 to 10 °F)
Sensor Offsets		
Evap pressure offset	0 KPA (0 PSI)	-100 to 100 KPA (-14.5 to 14.5 PSI)
Cond pressure offset	0 KPA (0 PSI)	-100 to 100 KPA (-14.5 to 14.5 PSI)
Suction temp offset	0°C (0°F)	-5.0 to 5.0 °C (-9.0 to 9.0 °F)

Note – Condenser Target 67% and Condenser Target 33% will be available only when Number of Compressors is 6. Condenser Target 50% will be available only when Number of Compressors is 4.

Auto Adjusted Ranges

Some settings have different ranges of adjustment based on other settings:

Cool LWT 1, Cool LWT 2, and Network Cool Set Point	
Available Mode Selection	Range
Without Glycol	4.4 to 15.6 °C (39.9 to 60.1 °F)
With Glycol	-9.5 to 15.6 °C (14.9 to 60.1 °F)

Evaporator Water Freeze	
Available Mode Selection	Range
Without Glycol	2.2 to 5.6 °C (36 to 42.1 °F)
With Glycol	-10.8 to 5.6 °C (12.6 to 42.1 °F)

Low Evaporator Pressure Hold and Unload	
Available Mode Selection	Range
Without Glycol	669 to 793 KPA (97 to 115 PSI)
With Glycol	407 to 793 KPA (59 to 115 PSI)

Special Set Point Operations

The following setpoints are not changeable unless the unit switch is off:

- Available Modes
- Number of Compressors
- Expansion Valve Type
- Number of Fans
- Fan VFD Enable

The Circuit Mode setpoints should not be changeable unless the corresponding circuit switch is off. The Compressor Enable setpoints should not be changeable unless the corresponding compressor is not running.

EXV Position set point on each circuit follows the actual EXV position while EXV Control = Auto. When EXV Control = Manual, the position set point should be changeable.

The Clear Alarms and Network Clear Alarms settings are automatically set back to Off after being On for 1 second.

Security

All setpoints are protected using passwords. A four-digit password provides operator access to changeable parameters. Service level passwords are reserved for authorized service personnel. .

Operator password: 2526

Entering Passwords

Passwords are entered on the first screen on the unit controller,

If the wrong password is entered, a message will temporarily appear stating this. If no valid password is active the active password level displays “none”.

Editing Setpoints

After a valid password has been entered at the unit controller, setpoints may be changed. If the operator attempts to edit a setpoint for which the necessary password level is not active, no action will be taken.

Once a password has been entered, it remains valid for 10 minutes after the last key-press on the unit controller.

Unit Functions

Definitions

The calculations in this section are used in unit level and circuit control logic.

LWT Slope

LWT slope is calculated such that the slope represents the estimated change in LWT over a time frame of one minute.

Pulldown Rate

The slope value calculated above will be a negative value as the water temperature is dropping. A pulldown rate is calculated by inverting the slope value and limiting to a minimum value of 0°C/min.

LWT Error

LWT error is calculated as:

$$\text{LWT} - \text{LWT target}$$

Unit Capacity

For applying unit capacity limits, an estimate of total unit capacity is needed. Unit capacity will be based on the estimated circuit capacities.

The unit capacity is the number of compressors running (on circuits that are not pumping down) divided by the number of compressors on the unit.

Control Band

The Control Band defines the band in which unit capacity will not be increased or decreased.

The Control Band is calculated as follows:

- Four compressor units: Control Band = Nominal Evap Delta T Set Point * 0.3
- Six compressor units: Control Band = Nominal Evap Delta T Set Point * 0.2

Staging Temperatures

If the unit is configured for use without glycol:

When the LWT target is more than half the Control Band above 3.9°C (39.0°F)

- Stage Up Temperature = LWT target + (Control Band/2)
- Stage Down Temperature = LWT target – (Control Band/2)

If the LWT target is less than half the Control Band above 3.9°C (39.0°F)

- Stage Down Temperature = LWT target – (LWT target - 3.9°C)

:

Unit Switch	Control Source Set Point	Remote Switch Input	Unit Enable Set Point	BAS Enable Set Point	Unit Enable
Off					Off
			Off		Off
		Off			Off
On	Local	On	On		On
	Network			Off	Off
On	Network	On	On	On	On

- Stage Up temperature = LWT target + Control Band – (LWT target – 3.9°C)

If the unit is configured for use with glycol, the compressor staging temperatures are calculated as shown below:

- Stage Up Temperature = LWT target + (Control Band/2)
- Stage Down Temperature = LWT target – (Control Band/2)

The Start up and Shutdown temperatures are referenced from the Control Band:

- Start Up Temperature = Stage Up Temperature + Start Up Delta set point
- Shutdown Temperature = Stage Down Temperature – Shutdown Delta set point

Unit Enable

Enabling and disabling the chiller is accomplished using setpoints and inputs to the chiller. The unit switch, remote switch input, and Unit Enable Set Point all are required to be 'on' for the unit to be enabled when the control source is set to 'local'. The same is true if the control source is set to 'network', with the additional requirement that the building automation system (BAS) Enable set point must be 'on'. The BAS should enable the chiller only when there is a demand for cooling.

Unit is enabled according to the following table

Unit Mode Selection

The operating mode of the unit is determined by setpoints and inputs to the chiller. The Available Modes Set Point determines what modes of operation can be used. This set point also determines whether the unit is configured for glycol use. The Control Source Set Point determines where a command to change modes will come from. A digital input switches between cool mode and ice mode if they are available and the control source is set to 'local.' The BAS mode

request switches between cool mode and ice mode if they are both available and the control source is set to 'network.'

The Available Modes Set Point should only be changeable when the unit switch is off. This is to avoid changing modes of operation inadvertently while the chiller is running.

Unit Mode is set according to the following table:

Control Source Set Point	Mode Input	BAS Request	Available Modes Set Point	Unit Mode
			Cool	Cool
			Cool w/Glycol	Cool
Local	Off		Cool/Ice w/Glycol	Cool
Local	On		Cool/Ice w/Glycol	Ice
Network		Cool	Cool/Ice w/Glycol	Cool
Network		Ice	Cool/Ice w/Glycol	Ice
			Ice w/Glycol	Ice
			Test	Test

Glycol Configuration

If the Available Modes Set Point is set to an option 'w/Glycol', then glycol operation should be enabled for the unit. Glycol operation should only be disabled when the Available Modes Set Point is set to 'Cool'.

Unit States

The unit will always be in one of three states:

- Off – Unit is not enabled to run
- Auto – Unit is enabled to run
- Pumpdown – Unit is doing a normal shutdown

Transitions between these states are shown in the following diagram.




Diagram explanation on following page.

T1 - Off to Auto

All of the following are required:

- Unit Enable = On
- No Unit Alarm
- A circuit is enabled to start
- If Unit Mode = Ice then Ice Delay not active

T2 - Auto to Pumpdown

Any of the following are required:

- Unit Enable = Off and Unit Switch is closed
- Unit Mode = Ice AND LWT target is reached
- Unit Pumpdown Alarm active

T3 - Pumpdown to Off

Any of the following are required:

- Unit rapid stop alarm active
- All circuits complete pumpdown
- Unit Switch open

T4 - Auto to Off

Any of the following are required:

- Unit rapid stop alarm active
- No circuit enabled and no compressors running
- Unit Switch open

Power Up Start Delay

After powering up the unit, the motor protectors may not be engaged for up to 150 seconds. Therefore, after the control is powered up, no compressor can start for 150 seconds. In addition, the motor protect inputs are ignored during this time so as to avoid tripping a false alarm.

Ice Mode Start Delay

An adjustable start to start ice delay timer will limit the frequency with which the chiller may

start in Ice mode. The timer starts when the first compressor starts while the unit is in ice mode. While this timer is active, the chiller cannot restart in Ice mode. The time delay is adjustable via the Ice Time Delay set point.

The ice delay timer may be manually cleared to force a restart in ice mode. A set point specifically for clearing the ice mode delay is available. In addition, cycling the power to the controller should clear the ice delay timer.

Unit Status

The displayed unit status should be determined by the conditions in the following table:

Enum	Status	Conditions
0	Auto	Unit State = Auto
1	Motor Prot Delay	Unit State = Auto and MP start up delay is active
2	Off:Ice Mode Timer	Unit State = Off, Unit Mode = Ice, and Ice Delay = Active
3	Off:OAT Lockout	Unit State = Off and Low OAT Lockout is active
4	Off:All Cir Disabled	Unit State = Off and both circuits unavailable
5	Off:Unit Alarm	Unit State = Off and Unit Alarm active

Continued next page.

Enum	Status	Conditions
6	Off:Keypad Disable	Unit State = Off and Unit Enable Set Point = Disable
7	Off:Remote Switch	Unit State = Off and Remote Switch is open
8	Off:BAS Disable	Unit State = Off, Control Source = Network, and BAS Enable = false
9	Off:Unit Switch	Unit State = Off and Unit Switch = Disable
10	Off:Test Mode	Unit State = Off and Unit Mode = Test
11	Auto:Wait for load	Unit State = Auto, no circuits running, and LWT is less than the active set point + startup delta
12	Auto:Evap Recirc	Unit State = Auto and Evaporator State = Start
13	Auto:Wait for flow	Unit State = Auto, Evaporator State = Start, and Flow Switch is open
14	Auto:Pumpdown	Unit State = Pumpdown
15	Auto:Max Pulldown	Unit State = Auto, max pulldown rate has been met or exceeded
16	Auto:Unit Cap Limit	Unit State = Auto, unit capacity limit has been met or exceeded
17	Auto: High Ambient Limit	---
18	Config Changed, Reboot Required	A configuration change requiring a reboot has occurred but controller has not been rebooted yet.


Evaporator Pump Control

For control of the evaporator pumps, three evaporator pump control states should be used:

Off - No pump on.

- Start – Pump is on, water loop is being recirculated.
- Run – Pump is on, water loop has been recirculated and circuits can start if needed.

Transitions between these states are shown in the following diagram.



T1 – Off to Start

Requires any of the following

- Unit state = Auto
- LWT is less than the Evap Freeze set point – 0.6°C (1.1°F) and LWT sensor fault isn't active

T2 – Start to Run

Requires the following

- Flow ok for time longer than evaporator recirculate time set point

T3 – Run to Off

Requires all of the following

- Unit state is Off
- LWT is higher than the Evap Freeze set point or LWT sensor fault is active

T4 – Start to Off

Requires all of the following

- Unit state is Off
- LWT is higher than the Evap Freeze set point or LWT sensor fault is active

T5 – Run to Start

This transition should occur per the requirements for pump staging and evaporator flow loss alarm.

Pump selection

The pump output used will be determined by the Evap Pump Control set point. This setting allows the following configurations:

- #1 only – Pump 1 will always be used
- #2 only – Pump 2 will always be used
- Auto – The primary pump is the one with the least run hours, the other is used as a backup
- #1 Primary – Pump 1 is used normally, with pump 2 as a backup
- #2 Primary – Pump 2 is used normally, with pump 1 as a backup

Primary/Standby Pump Staging

The pump designated as primary will start first. If the evaporator state is start for a time greater than the recirculate timeout set point and there is no flow, then the primary pump will shut off and the standby pump will start. When the evaporator is in the run state, if flow is lost for more than half of the flow proof set point value, the primary pump will shut off and the standby pump will start. Once the standby pump is started, the flow loss alarm logic will apply if flow cannot be established in the evaporator start state, or if flow is lost in the evaporator run state.

Auto Control

If auto pump control is selected, the primary/standby logic above is still used. When the evaporator is not in the run state, the run hours of the pumps will be compared. The pump with the least hours will be designated as the primary at this time.

LWT Target

The LWT Target varies based on settings and inputs.

The base LWT Target is selected as follows:

Control Source Set Point	Mode Input	BAS Request	Available Modes Set Point	Base LWT Target
Local	OFF		COOL	Cool Set Point 1
Local	ON		COOL	Cool Set Point 2
Network			COOL	BAS Cool Set Point
Local	OFF		COOL w/Glycol	Cool Set Point 1
Local	ON		COOL w/Glycol	Cool Set Point 2
Network			COOL w/Glycol	BAS Cool Set Point

Local	OFF		COOL/ICE w/Glycol	Cool Set Point 1
Local	ON		COOL/ICE w/Glycol	Ice Set Point
Network		COOL	COOL/ICE w/Glycol	BAS Cool Set Point
Network		ICE	COOL/ICE w/Glycol	BAS Ice Set Point
Local			ICE w/Glycol	Ice Set Point
Network			ICE w/Glycol	BAS Ice Set Point

Leaving Water Temperature (LWT) Reset

The base LWT target may be reset if the unit is in Cool mode and LWT reset is enabled via the set point.

The reset amount is adjusted based on the 4 to 20 mA reset input. Reset is 0° if the reset signal is less than or equal to 4 mA. Reset is 5.56°C (10.0°F) if the reset signal equals or exceeds 20 mA. The amount of reset will vary linearly between these extremes if the reset signal is between 4 mA and 20 mA.

When the reset amount increases, the Active LWT Target is changed at a rate of 0.1°C every 10 seconds. When the active reset decreases, the Active LWT Target is changed all at once.

After the reset is applied, the LWT target can never exceed a value of 15.56°C (60°F).

Unit Capacity Control

Unit capacity control will be performed as described in this section. All unit capacity limits described in following sections must be applied as described.

Compressor Staging in Cool Mode

The first compressor on the unit should be started when evaporator LWT is higher than the Startup Temperature.

Additional compressors can be started when Evaporator LWT is higher than the Stage Up Temperature and the Stage Up Delay is not active.

When multiple compressors are running, one should shut down if evaporator LWT is lower than the Stage Down Temperature and the Stage Down Delay is not active.

All running compressors should shut down when the evaporator LWT is lower than the Shut Down Temperature.

Stage Up Delay

A minimum amount of time, defined by the Stage Up Delay set point, should pass between increases in the capacity stage. This delay should only apply when at least one compressor is running. If the first compressor starts and quickly shuts off for some reason, another compressor may start without this minimum time passing.

Stage Down Delay

A minimum amount of time, defined by the Stage Down Delay set point, should pass between decreases in the capacity stage. This delay should not apply when the LWT drops below the Shut Down Temperature (unit should immediately shut down).

Compressor Staging in Ice Mode

The first compressor on the unit should be started when evaporator LWT is higher than the Startup Temperature.

Additional compressors should be started as quickly as possible with respect to the Stage Up Delay.

The unit should shut down when evaporator LWT is less than the LWT target.

Stage Up Delay

A fixed stage up delay of one minute between compressor starts should be used in this mode.

Staging Sequence

This section defines which compressor is the next one to start or stop. In general, compressors with fewer starts will normally start first, and compressors with more run hours will normally stop first.

If possible circuits will be balanced in stage. If a circuit is unavailable for any reason, the other circuit shall be allowed to stage all compressors on. When staging down, one compressor on each circuit shall be left on until each circuit has only one compressor running.

Next To Start

If both circuits have an equal number of compressors running or a circuit has no compressors available to start:

- -the available compressor with the least starts will be next to start
- -if starts are equal, the one with the least run hours will be next to start
- -if run hours are equal, the lowest numbered one will be next to start

If the circuits have an unequal number of compressors running, the next compressor to start will be on the circuit with the least compressors running if it has at least one compressor available to start. Within that circuit:

- -the available compressor with the least starts will be next to start
- -if starts are equal, the one with the least run hours will be next to start
- -if run hours are equal, the lowest numbered one will be next to start

Next to Stop

If both circuits have an equal number of compressors running:

- -the running compressor with the most run hours will be next to stop
- -if run hours are equal, the one with the least starts will be next to stop
- -if starts are equal, the lowest numbered one will be next to stop

If the circuits have an unequal number of compressors running, the next compressor to stop will be on the circuit with the most compressors running. Within that circuit:

- -the running compressor with the most run hours will be next to stop
- -if run hours are equal, the one with the least starts will be next to stop
- -if starts are equal, the lowest numbered one will be next to stop

Unit Capacity Overrides

Unit capacity limits can be used to limit total unit capacity in Cool mode only. Multiple limits may be active at any time, and the lowest limit is always used in the unit capacity control.

Demand Limit

The maximum unit capacity can be limited by a 4 to 20 mA signal on the Demand Limit analog input. This function is only enabled if the Demand Limit set point is set to ON. The maximum unit capacity stage is determined as shown in the following tables:

Four Compressors:

Demand Limit Signal (%)	Demand Limit (mA)	Stage Limit
Limit \geq 75%	Limit \geq 16 mA	1
75% > Limit \geq 50%	16 mA > Limit \geq 12 mA	2
50% > Limit \geq 25%	12 mA > Limit \geq 8 mA	3
25% > Limit	8 mA > Limit	4

Six Compressors:

Demand Limit Signal (%)	Demand Limit (mA)	Stage Limit
Limit \geq 83.3%	Limit \geq 17.3 mA	1
83.3% > Limit \geq 66.7%	17.3 mA > Limit \geq 14.7 mA	2
66.7% > Limit \geq 50%	14.7 mA > Limit \geq 12mA	3
50% > Limit \geq 33.3%	12 mA > Limit \geq 9.3 mA	4
33.3% > Limit \geq 16.7%	9.3 mA > Limit \geq 6.7 mA	5
16.7% > Limit	6.7 mA > Limit	6

Network Limit

The maximum unit capacity can be limited by a network signal. This function is only enabled if the control source is set to network. The maximum unit capacity stage is based on the network limit value received from the BAS, and is determined as shown in the following tables:

Four compressors:

Network Limit	Stage Limit
Limit \geq 100%	4
100% > Limit \geq 75%	3
75% > Limit \geq 50%	2
50% > Limit	1

Six compressors:

Network Limit	Stage Limit
Limit \geq 100%	6
100% > Limit \geq 83.3%	5
83.3% > Limit \geq 66.7%	4
66.7% > Limit \geq 50%	3
50% > Limit \geq 33.3%	2
33.3% > Limit	1

Maximum LWT Pulldown Rate

The maximum rate at which the leaving water temperature can drop shall be limited by the Maximum Pulldown Rate set point, only when the unit mode is Cool.

If the rate exceeds this set point, no more compressors shall be started until the pulldown rate is less than the set point.

Running compressors will not be stopped as a result of exceeding the maximum pulldown rate.

High Ambient Limit

On units configured with single point power connections, the maximum load amps could be exceeded at high ambient temperatures. If all compressors are running on circuit 1 or all but one compressor on circuit 1, power connection is single point, and the outdoor air temperature OAT is greater than 46.6°C (115.9°F), circuit 2 is limited to running all but one compressor. This limit will allow the unit to operate at higher temperatures than 46.6°C (115.9°F).

Circuit Functions

Definitions

Refrigerant Saturated Temperature

- Refrigerant saturated temperature shall be calculated from the pressure sensor readings for each circuit.

Evaporator Approach

The evaporator approach shall be calculated for each circuit. The equation is as follows:

$$\text{Evaporator Approach} = \text{LWT} - \text{Evaporator Saturated Temperature}$$

Condenser Approach

The condenser approach shall be calculated for each circuit. The equation is as follows:

$$\text{Condenser Approach} = \text{Condenser Saturated Temperature} - \text{OAT}$$

Suction Superheat

Suction superheat shall be calculated for each circuit using the following equation:

$$\text{Suction superheat} = \text{Suction Temperature} - \text{Evaporator Saturated Temperature}$$

Pumpdown Pressure

The pressure to which a circuit will pumpdown is based on the Low Evaporator Pressure Unload set point. The equation is as follows:

$$\text{Pumpdown pressure} = \text{Low Evap Pressure Unload set point} - 103\text{KPA (15 PSI)}$$

Circuit Control Logic

Circuit Enabling

A circuit should be enabled to start if the following conditions are true:

- Circuit switch is closed
- No circuit alarms are active
- Circuit Mode set point is set to Enable
- At least one compressor is enabled to start (according to enable setpoints)

Compressor Availability

A compressor is considered available to start if all the following are true:


- The corresponding circuit is enabled
- The corresponding circuit is not in pumpdown
- No cycle timers are active for the compressor
- No limit events are active for the corresponding circuit
- The compressor is enabled via the enable setpoints
- The compressor is not already running

Circuit States

The circuit will always be in one of four states:

- Off – Circuit is not running
- Preopen – Circuit is preparing to start
- Run – Circuit is running
- Pumpdown – Circuit is doing a normal shutdown

Transitions between these states are shown in the following diagram.



T1 – Off to Preopen

- No compressors are running and any compressor on circuit is commanded to start (see unit capacity control)

•

T2 – Preopen to Run

- 5 seconds has passed

T3 – Run to Pumpdown

Any of the following are required:

- Last compressor on circuit is commanded to stop
- Unit State = Pumpdown
- Circuit switch is open
- Circuit mode is disable
- Circuit Pumpdown alarm is active

T4 – Pumpdown to Off

Any of the following are required:

- Evaporator Pressure < Pumpdown Pressure Value
- Unit State = Off
- Circuit Rapid Stop alarm is active

T5 – Run to Off

Any of the following are required:

- Unit State = Off
- Circuit Rapid Stop alarm is active
- A low ambient start attempt failed

T6 – Preopen to Off

Any of the following are required:

- Unit State = Off
- Unit State = Pumpdown
- Circuit switch is open
- Circuit mode is disable
- Circuit Rapid Stop alarm is active
- Circuit Pumpdown alarm is active

Pumpdown Procedure

Pumpdown is performed as follows:

- If multiple compressors are running, shut off the appropriate compressors based on sequencing logic and leave only one running
- Turn off hot gas output and liquid line output
- Keep running until evaporator pressure reaches the pumpdown pressure, then stop compressor
- If evaporator pressure does not reach pumpdown pressure within two minutes, stop compressor

Low Ambient Starts

A low OAT start is initiated if the condenser refrigerant saturated temperature is less than 29.5°C (85.1° F) when the first compressor starts. Once the compressor starts the circuit is in a low OAT start state for a time equal to the Low OAT Start Time set point. During Low OAT Starts, the freestat logic for the low evaporator pressure alarm as well as the low evaporator pressure hold

and unload alarms are disabled. The absolute limit for low evaporator pressure is enforced and the low evaporator pressure alarm should trigger if the evaporator pressure drops below that limit.

When the Low OAT Start Timer has expired, if the evaporator pressure is greater than or equal to the Low Evaporator Pressure Unload set point, the start is considered successful and normal alarm and event logic is reinstated. If the evaporator pressure is less than the Low Evaporator Pressure Unload set point when the Low OAT Start Timer expires, the start is unsuccessful and the compressor will shutdown.

Multiple Low Ambient Start attempts are allowed. On the third failed Low Ambient Start attempt the Restart Alarm is triggered and the circuit will not attempt to restart until the Restart alarm has been cleared.

The restart counter should be reset when either a startup is successful, the Low OAT Restart alarm is triggered, or the unit time clock shows that a new day has started.

Circuit Status

The displayed circuit status should be determined by the conditions in the following table:

Enum	Status	Conditions
0	Off:Ready	Circuit is ready to start when needed.
1	Off:Cycle Timers	Circuit is off and cannot start due to active cycle timer on all compressors.
2	Off:All Comp Disable	Circuit is off and cannot start due to all compressors being disabled.
3	Off:Keypad Disable	Circuit is off and cannot start due to circuit enable set point.
4	Off:Circuit Switch	Circuit is off and circuit switch is off.
5	Off:Alarm	Circuit is off and cannot start due to active circuit alarm.
6	Off:Test Mode	Circuit is in test mode.
7	Preopen	Circuit is in preopen state.
8	Run:Pumpdown	Circuit is in pumpdown state.
9	Run:Normal	Circuit is in run state and running normally.
10	Run:Evap Press Low	Circuit is running and cannot load due to low evaporator pressure.
11	Run:Cond Press High	Circuit is running and cannot load due to high condenser pressure.
12	Run:High OAT Limit	Circuit is running and cannot add more compressors due to the high ambient limit on unit capacity. Applies only to circuit 2.

Compressor Control

Compressors should run only when the circuit is in a run or pumpdown state. They should not be running when the circuit is in any other state.

Starting a Compressor

A compressor should start if it receives a start command from the unit capacity control logic.

Stopping a Compressor

A compressor should be turned off if any of the following occur:

- Unit capacity control logic commands it off
- An unload alarm occurs and the sequencing requires this compressor to be next off
- Circuit state is pumpdown and sequencing requires this compressor to be next off

Cycle Timers

A minimum time between starts of the compressor and a minimum time between shutdown and start of the compressor shall be enforced. The time values are determined by the Start-start Timer and Stop-start Timer setpoints.

These cycle timers should not be enforced through cycling of power to the chiller. This means that if power is cycled, the cycle timers should not be active.

These timers may be cleared via a setting on the human machine interface (HMI).

Condenser Fan Control

Condenser fan control should stage fans as needed any time compressors are running on the circuit. All running fans should turn off when the circuit goes to the off state.

Fan Staging

Fan staging shall accommodate anywhere from 2 to 7 fans on a circuit using up to 5 outputs for control. The total number of fans on shall be adjusted with changes of one fan at a time. The tables below show the outputs energized for each stage.

2 Through 4 Fans	
Stage	Fan Outputs On
1	1
2	1,2
3	1,2,3
4	1,2,3,4

5 Fans	
Fan Stage	Fan Outputs On
1	1
2	1,2
3	1,2,3
4	1,2,4
5	1,2,3,4

6 Fans	
Fan Stage	Fan Outputs On
1	1
2	1,2
3	1,2,3
4	1,2,4
5	1,2,3,4
6	1,2,3,4,5

7 Fans	
Fan Stage	Fan Outputs On
1	1
2	1,2
3	1,2,3
4	1,2,4
5	1,2,3,4
6	1,2,4,5
7	1,2,3,4,5

Condenser Target

A condenser target should be selected from the setpoints based on the number of compressors on the unit and the number of compressors running. Each stage of capacity on a circuit will use a different condensing target set point.

A minimum condenser target should be enforced. This minimum will be calculated based on the evaporator LWT. As the LWT varies from 7.2°C (45°F) to 32.2°C (90°F), the minimum condenser target will vary from 23.9°C (75°F) to 48.9°C (120°F).

Staging Up

The first fan should turn on when the saturated condenser temperature exceeds the condenser target. After this, the four stage up dead bands shall be used. Stages one through four should use their respective dead bands. Stages five through six should all use the Stage Up Dead Band 4.

When the saturated condenser temperature is above the target + the active deadband, a stage up error is accumulated.

Stage Up Error Step = Saturated Condenser Temperature – (Target + Stage Up dead band)

The Stage Up Error Step is added to Stage Up Accumulator once every 5 seconds, only if the Saturated Condenser Refrigerant Temperature is not falling. When Stage Up Error Accumulator is greater than 11°C (19.8°F) another stage is added.

When a stage up occurs or the saturated condenser temperature falls back within the stage up dead band the Stage Up Accumulator is reset to zero.

Staging Down

Four stage down dead bands shall be used. Stages one through four should use their

Stage Up Compensation

In order to create a smoother transition when another fan is staged on, the VFD compensates by slowing down initially. This is accomplished by adding the new fan stage up deadband to the VFD target. The higher target causes the VFD logic to decrease fan speed. Then, every 2 seconds, 0.1°C (0.18°F) is subtracted from the VFD target until it is equal to the saturated condenser temperature target set point.

respective dead bands. Stages five through seven should all use Stage Down Dead Band 4.

When the saturated condenser refrigerant temperature is below the target – the active deadband, a stage down error is accumulated.

Stage Down Error Step = (Target - Stage Down dead band) - Saturated Condenser Temperature

The Stage Down Error Step is added to Stage Down Accumulator once every 5 seconds. When the Stage Down Error Accumulator is greater than 2.8°C (5°F) another stage of condenser fans is removed.

When a stage down occurs or the saturated temperature rises back within the Stage Down dead band the Stage Down Error Accumulator is reset to zero.

VFD

Condenser pressure trim control is accomplished using an optional VFD on the first fan. This VFD control should vary the fan speed to drive the saturated condenser temperature to a target value. The target value is normally the same as the saturated condenser temperature target.

The speed should be controlled between the minimum and maximum speed setpoints.

VFD State

The VFD speed signal should always be 0 when the fan stage is 0.

When the fan stage is greater than 0, the VFD speed signal should be enabled and control the speed as needed.

EXV Control

Auto Control

Any time the circuit is not in the run state, the EXV position should be 0. The EXV control state should display that the EXV state is closed when this is the case.

While a circuit is in the run state, the EXV should go into superheat control. While in superheat control, the EXV controls suction superheat. The suction superheat target is set by a set point. A PID function will be used to control the superheat to the target value.

The EXV should also prevent the evaporator pressure from exceeding the Maximum

Evaporator Pressure set point. This is done by using another PID function to control evaporator pressure to the maximum evaporator pressure.

The EXV position should be lesser position output from the two PID functions.

EXV Position Range

The following table shows the EXV range based on the number of compressors running and the total number of fans on the unit.

		Compressors Running		
		1	2	3
Num Fans = 4	EXV Min	8%	8%	-
	EXV Max	40%	60%	-
Num Fans = 6	EXV Min	8%	8%	-
	EXV Max	60%	100%	-
Num Fans = 8	EXV Min	8%	8%	8%
	EXV Max	40%	55%	70%
Num Fans ≥ 10	EXV Min	8%	8%	8%
	EXV Max	30%	40%	50%

On units equipped with 10 or more condenser fans (shell and tube type evaporator):

When staging down a compressor the maximum position is reduced by 10% for one minute to prevent liquid from getting to compressors. After this initial one minute delay, the valve's maximum is allowed to return to its normal value at a rate of 0.1% every six seconds. This offset to the maximum position should not occur if the stage down is due to a low pressure unload.

In addition, the expansion valve maximum position may be increased if after two minutes both the suction superheat is greater than 7.2°C (13°F) and the expansion valve has been within 5% of its current maximum position. The maximum should increase at a rate of 0.1% every six

seconds up to a total of an additional 10%. This offset to the maximum position should be reset when the EXV is no longer in the Superheat Control state or a compressor on the circuit stages.

Manual Control

The EXV position can be set manually. Manual control can only be selected when the circuit is in the run state. At any other time, the EXV control set point is forced to auto.

When EXV control is set to manual, the EXV position is equal to the manual EXV position setting. If set to manual when the circuit state transitions from run to another state, the control setting is automatically set back to auto. When in manual control, the EXV control state displayed should reflect that it is manual control.

Liquid Line Solenoid Valve

The liquid line solenoid output should be on when the circuit state is either Pre-open or Run. This output should be off at all other times.

Hot Gas Bypass Solenoid Valve

This output shall be on when circuit state is Run and one compressor on the circuit is running. The output should be off at all other times.

Capacity Overrides – Limits of Operation

The following conditions shall override automatic capacity control as described. These overrides

Alarms

Situations may arise that require some action from the chiller or that should be logged for future reference. Alarms are classified in the following sections per the Global Chiller Protocol Standard using the Fault/Problem/Warning scheme.

When any Unit Fault Alarm is active, the alarm digital output should be turned on. If no Unit

keep the circuit from entering a condition in which it is not designed to run.

Low Evaporator Pressure

If the Low Evaporator Pressure Hold or Low Evaporator Pressure Unload alarms are triggered, the circuit capacity may be limited or reduced. See the Circuit Events section for details on triggering, reset, and actions taken.

High Condenser Pressure

If the High Condenser Pressure Unload alarm is triggered, the circuit capacity may be limited or reduced. See the Circuit Events section for details on triggering, reset, and actions taken.

Fault Alarm is active, but any Circuit Fault Alarm is active, the alarm digital output should alternate five seconds on and five seconds off continuously.

All alarms appear in the active alarm list while active. All alarms are added to the alarm log when triggered and when cleared.

Unit Fault Alarms

PVM/GFP Fault

Trigger: Power Configuration = Single Point and PVM/GFP Input #1 is open.

Action Taken: Rapid stop all circuits

Reset: Auto reset when input is closed for at least 5 seconds or if Power Configuration = Multi Point.

Evaporator Flow Loss

Trigger:

1: Evaporator Pump State = Run AND Evaporator Flow Digital Input = No Flow for time > Flow Proof Set Point AND at least one compressor running

2: Evaporator Pump State = Start for time greater than Recirc Timeout Set Point and all pumps have been tried and Evaporator Flow Digital Input = No Flow

Action Taken: Rapid stop all circuits

Reset:

This alarm can be cleared at any time manually via the keypad or via the BAS clear alarm command.

If active via trigger condition 1:

When the alarm occurs due to this trigger, it can auto reset the first two times each day with the third occurrence being manual reset.

For the auto reset occurrences, the alarm will reset automatically when the evaporator state is Run again. This means the alarm stays active while the unit waits for flow, then it goes through the recirculation process after flow is detected. Once the recirculation is complete, the evaporator goes to the Run state which will clear the alarm. After three occurrences, the count of occurrences is reset and the cycle starts over if the manual reset flow loss alarm is cleared.

If active via trigger condition 2:

If the flow loss alarm has occurred due to this trigger, it is always a manual reset alarm.

Evaporator Water Freeze Protect

Trigger: Evaporator LWT drops below evaporator freeze protect set point and LWT sensor fault is not active.

Action Taken: Rapid stop all circuits

Reset: This alarm can be cleared manually via the keypad, but only if the alarm trigger conditions no longer exist.

Evaporator LWT Sensor Fault

Trigger: Sensor shorted or open

Action Taken: Normal stop all circuits

Reset: This alarm can be cleared manually via the keypad or BAS command, but only if the sensor is back in range.

Outdoor Air Temperature Sensor Fault

Trigger: Sensor shorted or open

Action Taken: Normal stop of all circuits.

Reset: This alarm can be cleared manually via the keypad or via BAS command if the sensor is back in range.

External Alarm

Trigger: External Alarm/Event opens for at least 5 seconds and external fault input is configured as an alarm.

Action Taken: Rapid stop of all circuits.

Reset: Auto clear when digital input is closed.

Compressor Module 1 Comm Failure

Trigger: Communication with the I/O extension module has failed.

Action Taken: Rapid stop of circuit 1.

Reset: This alarm can be cleared manually via the keypad or BAS command when communication between main controller and the extension module is working for 5 seconds.

Compressor Module 2 Comm Failure

Trigger: Communication with the I/O extension module has failed.

Action Taken: Rapid stop of circuit 2.

Reset: This alarm can be cleared manually via the keypad or BAS command when communication between main controller and the extension module is working for 5 seconds.

EXV Module 1 Comm Failure

Trigger: Expansion Valve Type = Electronic and communication with the I/O extension module has failed.

Action Taken: Rapid stop of circuit 1.

Reset: This alarm can be cleared manually via the keypad or BAS command when communication between main controller and the extension module is working for 5 seconds or Expansion Valve Type = Thermal.

EXV Module 2 Comm Failure

Trigger: Expansion Valve Type = Electronic and communication with the I/O extension module has failed.

Action Taken: Rapid stop of circuit 2.

Reset: This alarm can be cleared manually via the keypad or BAS command when communication between main controller and the extension module is working for 5 seconds or Expansion Valve Type = Thermal.

Unit Problem Alarms

Low Ambient Lockout (No longer an alarm from version 251699201 on)

Trigger: The OAT drops below the low ambient lockout set point AND the OAT sensor fault is not active.

Action Taken: Normal shutdown of all circuits.

Reset: The lockout should clear when OAT rises to the lockout set point plus 2.8°C (5°F).

Evaporator Pump #1 Failure

Trigger: Unit is configured with primary and backup pumps, pump #1 is running, and the pump control logic switches to pump #2.

Action Taken: Backup pump is used.

Reset: This alarm can be cleared manually via the keypad or BAS command

Evaporator Pump #2 Failure

Trigger: Unit is configured with primary and backup pumps, pump #2 is running, and the pump control logic switches to pump #1.

Action Taken: Backup pump is used.

Reset: This alarm can be cleared manually via the keypad or BAS command

Unit Warning Alarms

External Event

Trigger: External Alarm/Event input is open for at least 5 seconds and external fault is configured as an event.

Action Taken: None

Reset: Auto clear when digital input is closed.

Bad Demand Limit Input

Trigger: Demand limit input out of range and demand limit is enabled. For this alarm out of range is considered to be a signal less than 3mA or more than 21mA.

Action Taken: Cannot use demand limit function.

Reset: Auto clear when demand limit disabled or demand limit input back in range for 5 seconds.

Bad LWT Reset Input

Trigger: LWT reset input out of range and LWT reset is enabled. For this alarm out of range is considered to be a signal less than 3mA or more than 21mA.

Action Taken: Cannot use LWT reset function.

Reset: Auto clear when LWT reset is disabled or LWT reset input back in range for 5 seconds.

Evaporator EWT Sensor Fault

Trigger: Sensor shorted or open

Action Taken: None.

Reset: Auto clear when the sensor is back in range.

Circuit Fault Alarms

PVM/GFP Fault

Trigger: Power Configuration = Multi Point and circuit PVM/GFP input is open.

Action Taken: Rapid stop circuit.

Reset: Auto reset when input is closed for at least 5 seconds or if Power Configuration = Single Point.

Low Evaporator Pressure

Trigger:

This alarm should trigger when Freeze time is exceeded, Low Ambient Start is not active, and Circuit State = Run. It should also trigger if Evaporator Press < 137.9 KPA (20 PSI) and Circuit State = Run.

Freezestat logic allows the circuit to run for varying times at low pressures. The lower the pressure, the shorter the time the compressor can run. This time is calculated as follows:

Freeze error = Low Evaporator Pressure Unload – Evaporator Pressure

Freeze time =

For units equipped with 10 or more condenser fans (shell and tube type evaporator):

80 – freeze error, limited to a range of 40 to 80 seconds

For all other configurations (plate to plate type evaporator):

60 – freeze error, limited to a range of 20 to 60 seconds

When the evaporator pressure goes below the Low Evaporator Pressure Unload set point, a timer starts. If this timer exceeds the freeze time, then a freezestat trip occurs. If the evaporator pressure rises to the unload set point or higher, and the freeze time has not been exceeded, the timer will reset.

The alarm cannot trigger if the evaporator pressure sensor fault is active.

Action Taken: Rapid stop circuit.

Reset: This alarm can be cleared manually via the keypad if the evaporator pressure is above 137.9 KPA (20 PSI).

High Condenser Pressure

Trigger: Condenser Pressure > High Condenser Pressure set point

Action Taken: Rapid stop circuit

Reset: This alarm can be cleared manually via the controller keypad

Mechanical High Pressure Switch

Trigger: Mechanical High Pressure switch input is open, Motor Protection input is closed, and power up start delay is not active.

Action Taken: Rapid stop circuit.

Reset: This alarm can be cleared manually via the controller keypad if the MHP switch input is closed.

Motor Protection Fault

Trigger: Motor Protection input is open and power up start delay is not active.

Action Taken: Rapid stop circuit.

Reset: This alarm can be cleared manually via the controller keypad if the input is closed.

Low OAT Restart Fault

Trigger: Circuit has failed three low OAT start attempts.

Action Taken: Rapid stop circuit.

Reset: This alarm can be cleared manually via the keypad or via BAS command.

No Pressure Change After Start

Trigger: After start of compressor, at least a 7 KPA (1 PSI) drop in evaporator pressure OR 35 KPA (5.1 PSI) increase in condenser pressure has not occurred after 30 seconds. The actual alarm will not be triggered until the second occurrence.

Action Taken: Rapid stop circuit.

Reset: This alarm can be cleared manually via the keypad or via BAS command.

Evaporator Pressure Sensor Fault

Trigger: Sensor shorted or open.

Action Taken: Rapid stop circuit.

Reset: This alarm can be cleared manually via the keypad or BAS command, but only if the sensor is back in range.

Condenser Pressure Sensor Fault

Trigger: Sensor shorted or open.

Action Taken: Rapid stop circuit.

Reset: This alarm can be cleared manually via the keypad or BAS command, but only if the sensor is back in range.

Suction Temperature Sensor Fault

Trigger: Sensor shorted or open and Expansion Valve Type = Electronic.

Action Taken: Normal shutdown of circuit.

Reset: This alarm can be cleared manually via the keypad or BAS command, but only if the sensor is back in range.

Circuit Events

Low Evaporator Pressure - Hold

Trigger:

This event is triggered if all of the following are true:

- circuit state = Run
- evaporator pressure \leq Low Evaporator Pressure - Hold set point
- circuit is not currently in a low OAT start
- it has been at least 30 seconds since a compressor has started on the circuit.

Action Taken: Inhibit starting of additional compressors on the circuit.

Reset: While still running, the event will be reset if evaporator pressure $>$ Low Evaporator Pressure Hold SP + 90 KPA(13 PSI). The event is also reset if the circuit is no longer in the run state.

Low Evaporator Pressure - Unload

Trigger:

This event is triggered if all of the following are true:

- circuit state = Run
- more than one compressor is running on the circuit
- evaporator pressure \leq Low Evaporator Pressure - Unload set point for a time greater than half of the current freezestat time
- circuit is not currently in a low OAT start
- it has been at least 30 seconds since a compressor has started on the circuit.

On units equipped with 6 compressors, electronic expansion valves, and 10 or more fans, when each compressor starts, there should be a 2 minute window during which the evaporator pressure must drop an additional 27 KPA (3.9 PSI) to trigger the alarm. After this 2 minute window, the trigger point should return to normal.

Action Taken: Stage off one compressor on the circuit every 10 seconds, except the last one.

Reset: While still running, the event will be reset if evaporator pressure $>$ Low Evaporator Pressure Hold SP + 90 KPA(13 PSI). The event is also reset if the circuit is no longer in the run state.

High Condenser Pressure - Unload

Trigger:

This event is triggered if all of the following are true:

- circuit state = Run
- more than one compressor is running on the circuit
- condenser pressure $>$ High Condenser Pressure – Unload set point

Action Taken: Stage off one compressor on the circuit every 10 seconds while condenser pressure is higher than the unload set point, except the last one. Inhibit staging more compressors on until the condition resets.

Reset: While still running, the event will be reset if condenser pressure \leq High Condenser Pressure Unload SP – 862 KPA(125 PSI). The event is also reset if the circuit is no longer in the run state.

Circuit Warning Alarms

Failed Pumpdown

Trigger: Circuit state = pumpdown for longer than 2 minutes

Action Taken: Rapid stop circuit

Reset: N/A.

Events

Situations may arise that require some action from the chiller or that should be logged for future reference, but aren't severe enough to track as alarms. These events are stored in a log separate from alarms. This log shows the time and date of the latest occurrence, the count of occurrences for the current day, and the count of occurrences for each of the previous 7 days.

Unit Events

Unit Power Restore

Trigger: Unit controller is powered up.

Action Taken: none.

Reset: none.

Circuit Events

Low Evaporator Pressure - Hold

Trigger:

This event is triggered if all of the following are true:

- circuit state = Run
- evaporator pressure \leq Low Evaporator Pressure - Hold set point
- circuit is not currently in a low OAT start
- it has been at least 30 seconds since a compressor has started on the circuit.

Action Taken: Inhibit starting of additional compressors on the circuit.

Reset: While still running, the event will be reset if evaporator pressure $>$ Low Evaporator Pressure Hold SP + 90 KPA(13 PSI). The event is also reset if the circuit is no longer in the run state.

Low Evaporator Pressure - Unload

Trigger:

This event is triggered if all of the following are true:

- circuit state = Run
- more than one compressor is running on the circuit
- evaporator pressure \leq Low Evaporator Pressure - Unload set point for a time greater than half of the current freezestat time
- circuit is not currently in a low OAT start
- it has been at least 30 seconds since a compressor has started on the circuit

On units equipped with 6 compressors, electronic expansion valves, and 10 or more fans, when each compressor starts, there should be a 2 minute window during which the evaporator pressure must drop an additional 27 KPA (3.9 PSI) to trigger the alarm. After this 2 minute window, the trigger point should return to normal.

Action Taken: Stage off one compressor on the circuit every 10 seconds while evaporator pressure is less than the unload set point, except the last one.

Reset: While still running, the event will be reset if evaporator pressure $>$ Low Evaporator Pressure Hold SP + 90 KPA(13 PSI). The event is also reset if the circuit is no longer in the run state.

High Condenser Pressure - Unload

Trigger:

This event is triggered if all of the following are true:

- circuit state = Run
- more than one compressor is running on the circuit
- condenser pressure $>$ High Condenser Pressure – Unload set point

Action Taken: Stage off one compressor on the circuit every 10 seconds while condenser pressure is higher than the unload set point, except the last one. Inhibit staging more compressors on until the condition resets.

Reset: While still running, the event will be reset if condenser pressure \leq High Condenser Pressure Unload SP – 862 KPA(125 PSI). The event is also reset if the circuit is no longer in the run state.

Alarm Logs

NOTE: refer to **Error! Reference source not found.** on the following page for controller components. Press the alarm button on the controller to go to the alarm section. Three alarm sub-sections will appear. Turn the navigating wheel to highlight among them and press the wheel to select.

1. Active Alarms

When an alarm or event occurs, it appears in the active alarm list. The active alarm list holds a record of all active alarms not yet cleared and includes the date and time each occurred. When cleared, the alarm transfers to the Alarm Log that contains an alarm history with time/date stamp. A (+) before an alarm indicates that it is active, a (-) indicates a cleared alarm. The Active Alarm list is only limited by the number of alarms since any given alarm cannot appear twice.

2. Alarm Log

An alarm log stores the last 50 occurrences or resets that occur. When an alarm or event occurs, it is put into the first slot in the alarm log and all others are moved down one, dropping the last entry. The date and time the alarm occurred are stored in the alarm log.

3. Event Log

An Event Log similar to the Alarm Log stores the last 50 event occurrences. Each Event Log entry includes an event description and a time and date stamp for the event occurrence plus the count of the event occurrences on the

current day and for each of the last seven days. Events do not appear in the Active Alarm list.

Clearing Alarms

Active alarms can be cleared through the keypad/display or a BAS network. Alarms are automatically cleared when controller power is cycled. Alarms are cleared only if the conditions required to initiate the alarm no longer exist. All alarms and groups of alarms can be cleared via the keypad or network via LON using nviClearAlarms and via BACnet using the ClearAlarms object.


To use the keypad, follow the Alarm links to the Alarms screen, which will show Active Alarms and Alarm Log. Select Active Alarm and press the wheel to view the Alarm List (list of current active alarms). They are in order of occurrence with the most recent on top. The second line on the screen shows Alm Cnt (number of alarms currently active) and the status of the alarm clear function. Off indicates that the Clear function is off and the alarm is not cleared. Press the wheel to go to the edit mode. The Alm Clr (alarm clear) parameter will be highlighted with OFF showing. To clear all alarms, rotate the wheel to select ON and enter it by pressing the wheel.

An active password is not necessary to clear alarms.

If the problem(s) causing the alarm have been corrected, the alarms will be cleared, disappear from the Active Alarm list and be posted in the Alarm Log. If not corrected, the On will immediately change back to OFF and the unit will remain in the alarm condition

Using the Controller

Figure 3, Unit Controller



The keypad/display consists of a 5-line by 22-character display, three buttons (keys) and a “push and roll” navigation wheel. There is an Alarm Button, Menu (Home) Button, and a Back Button. The wheel is used to navigate between lines on a screen (page) and to increase and decrease changeable values when editing. Pushing the wheel acts as an Enter Button and will jump from a link to the next set of parameters.

Figure 4, Typical Screen

◆ 3	View/Set Unit 3	
	Status/Settings	>
	Set Up	>
	Temperature	>
	Date/Time/Schedule	>

Generally, each line on the display contains a menu title, a parameter (such as a value or a setpoint), or a link (which will have an arrow in the right of the line) to a further menu.

The first line visible on each display includes the menu title and the line number to which the cursor is currently “pointing”, in the above case 3, Temperature.

The left most position of the title line includes an “up” arrow ▲ to indicate there are lines (parameters) “above” the currently displayed line; and/or a “down” arrow ▼ to indicate there are lines (parameters) “below” the currently displayed items or an “up/down” arrow ◆ to indicate there are lines “above and below” the currently displayed line. The selected line is highlighted.

Each line on a screen can contain status-only information or include changeable data fields (setpoints).

When the cursor is on a line the highlights will look like this:

If line contains a changeable value>

Evaporator Delta T= 10.0F

If the line contains status-only information>

Unit Status=	Run
--------------	-----

Or a line in a menu may be a link to further menus. This is often referred to as a jump line, meaning pushing the navigation wheel will cause a “jump” to a new menu. An arrow (>) is displayed to the far right of the line to indicate it is a “jump” line and the entire line is highlighted when the cursor is on that line.

NOTE - Only menus and items that are applicable to the specific unit configuration are displayed.

This manual includes information relative to the operator level of parameters; data and setpoints necessary for the every day operation of the chiller. There are more extensive menus available for the use of service technicians.

Navigating

When power is applied to the control circuit, the controller screen will be active and display the Home screen, which can also be accessed by pressing the Menu Button. The navigating wheel is the only navigating device necessary, although the MENU, ALARM, and BACK buttons can provide shortcuts as explained later.

Passwords

Enter passwords from the Main Menu:

Enter Password, links to the Entry screen, which is an editable screen. So pressing the wheel goes to the edit mode where the password (5321) can be entered. The first (*) will be highlighted, rotate the wheel clockwise to the first number and set it by pressing the wheel. Repeat for the remaining three numbers.

The password will time out after 10 minutes, and is cancelled if a new password is entered or the control powers down.

Figure 5, Password Menu

	Main Menu
Enter Password	>
Unit Status	
Off: Unit Sw	
ACTIVE SETPT	44.6°F

Figure 6, Password Entry Page

	Enter Password
Enter PW	****

Entering an invalid password has the same effect as not entering a password.

Once a valid password has been entered, the controller allows further changes and access without requiring the user to enter a password until either the password timer expires or a different password is entered.

Navigation Mode

When the navigation wheel is turned clockwise, the cursor moves to the next line (down) on the page. When the wheel is turned counter-clockwise the cursor moves to the previous line (up) on the page. The faster the wheel is turned the faster the cursor moves. Pushing the wheel acts as an “Enter” button.

Three types of lines exist:

- Menu title, displayed in the first line as in Figure 6.
- Link (also called Jump) having an arrow (>) in the right of the line and used to link to the next menu.
- Parameters with a value or adjustable setpoint.

For example, “Time Until Restart” jumps from level 1 to level 2 and stops there.

When the Back Button is pressed the display reverts back to the previously displayed page. If the Back button is repeatedly pressed the display continues to revert one page back along the current navigation path until the “main menu” is reached.

When the Menu (Home) Button is pressed the display reverts to the “main page.”

When the Alarm Button is depressed, the Alarm Lists menu is displayed.

Edit Mode

The Editing Mode is entered by pressing the navigation wheel while the cursor is pointing to a line containing an editable field. Turning the wheel clockwise while the editable field is highlighted causes the value to be increased. Turning the wheel counter-clockwise while the editable field is highlighted causes the value to be decreased. The faster the wheel is turned the faster the value is increased or decreased. Pressing the wheel again cause the new value to be saved and the keypad/display to leave the edit mode and return to the navigation mode.

A parameter with an “R” is read only; it is giving a value or description of a condition. An “R/W” indicates a read and/or write opportunity; a value can be read or changed (providing the proper password has been entered).

Example 1: Check Status, for example-is the unit being controlled locally or by an external network? We are looking for the Unit Control Source. Since this is a unit status parameter, start at Main Menu and select View/Set Unit. There will be an arrow at the right side of the box, indicating that a jump to the next level is required. Press the wheel to execute the jump.

You will arrive at the Status/Settings link. There is an arrow indicating that this line is a link to a further menu. Press the wheel again to jump to the next menu, Unit Status/Settings.

Rotate the wheel to scroll down to Control Source and read the result.

Example 2; Change a Setpoint, the chilled water setpoint for example. This parameter is designated as Cool LWT 1 setpoint and is a unit parameter. From the Main Menu select View/Set Unit. The arrow indicated that this is link to a further menu.

Press the wheel and jump to the next menu View/Set Unit and use the wheel to scroll down to Temperatures. This again has an arrow and is a link to a further menu. Press the wheel and jump to the Temperatures menu, which contains temperatures values and setpoints. The first line is Evap LWT, rotate wheel until Cool LWT 1 is highlighted. Press the wheel to enter edit mode. Rotate wheel until new setpoint is reached, then press wheel to accept the new value and exit edit mode.

Example 3; Clear an Alarm, from the Main Menu scroll down to the Alarms line. Note the arrow indicating this line is a link. Press the wheel to jump to the next menu Alarms There are two lines here; Alarm Active and Alarm Log. Alarms are cleared from the Active Alarm link. Press the wheel to jump to the next screen. With the first line highlighted, press the wheel to enter edit mode. Rotate wheel until AlmClr is set to On, then press wheel to clear the alarms.

Menus

Screens with titles and contents are shown in leftmost column of Table 13. An identifier for each screen is also found in this column. Screen contents can include:

- Data
- Setpoints
- Links to other screens

Note that some parameters or links may not be visible due to the unit configuration.

Link visibility as well as read and write access to parameters is defined for each password level:

- R = readable/visible
- R/W = readable/writeable
- blank = not visible/accessible

Screen Navigational Links:

For each link on a screen, the linked screen is indicated in the rightmost column.

Example; the Enter Password screen links to screen U-2

For each screen, the screen(s) from which you can navigate to it is also shown on the same row as the screen identifier.

Example: Enter Password in screen U-2 is linked from Screen U-1

For most circuit or compressor level parameters, there is a link to a screen that shows the values for all circuits/compressors which is indicated in the 'Links to screen' column as *.

For many of the circuit level screens, only one screen will be shown in this document. The same set of screens exists for each circuit and compressor. These screens are identified with 'Cx' and Cmpx' identifiers. 'U' designates a unit related screen.

Table 13, Menu Screens

NOTE: Bold entries indicate screens with links to other screens.

Screen U-1			
Main Menu	No password	Operator	Links to screen
Enter Password	R	R	U-2
Quick Menu		R	U-3
View/Set Unit		R	U-4
View/Set Circuit		R	U-5
Unit Status	R	R	
Active Setpoint	R	R	
Evap Leaving Water Temp	R	R	
Unit Capacity	R	R	
Unit Mode	R	R	
Time Until Restart	R	R	U-6
Alarms	R	R	U-7
Scheduled Maintenance	R	R	U-8
Review Operation			U-9
Manual Control			U-10
Commission Unit			U-11
About Chiller		R	U-12

Screen U-2

Enter Password
Enter PW

From Screen U-1

No password	Operator	Links to screen
R/W	R/W	

Screen U-3

Quick Menu
Unit Status
Active Setpoint
Evap Leaving Water Temp
Evap Entering Water Temp
Unit Capacity
Network Limit Value
Demand Limit Value
Unit Mode
Control Source

From Screen U-1

No password	Operator	Links to screen
	R	
	R	
	R	
	R	
	R	
	R	
	R	
	R	
	R	
	R/W	

Screen U-4

View/Set Unit
Status/Settings
Set-Up
Temperatures
Date/Time/Schedules
Power Conservation
LON Setup
BACnet IP Setup
BACnet MSTP Setup
Modbus Setup
AWM Setup
Configuration
Ctrlr IP Setup
Design Conditions
Alarm Limits
Calibrate Sensors
Settings Change History
Menu Password

From Screen U-1

No password	Operator	Links to screen
	R	U-13
	R	U-14
	R	U-15
	R	U-16
	R	U-17
	R	U-18
	R	U-19
	R	U-20
	R	U-21
	R	U-22
		U-23
	R	U-24
	R	U-25
	R	U-26
		U-27
		U-28
	R	U-29

Screen U-5

View/Set Circuit
Circuit #1
Circuit #2

From Screen U-1

No password	Operator	Links to screen
	R	Cx-1
	R	Cx-1

Screen U-6

Time Until Restart
Compressor 1 Cycle Time Remaining
Compressor 2 Cycle Time Remaining
Compressor 3 Cycle Time Remaining

From Screen U-1

No password	Operator	Links to screen
R	R	
R	R	
R	R	

Continued next page.

Screen U-6	From Screen U-1		
	No password	Operator	Links to screen
Time Until Restart			
Compressor 4 Cycle Time Remaining	R	R	
Compressor 5 Cycle Time Remaining	R	R	
Compressor 6 Cycle Time Remaining	R	R	
Clear Cycle Timers			

Screen U-7
Alarms
Alarm Active
Alarm Log
Event Log

From Screen U-1		
No password	Operator	Links to screen
R	R	U-30
R	R	U-31
	R	U-32

Screen U-8
Scheduled Maintenance
Next Maintenance Month/Year
Service Support Reference

From Screen U-1, U-9, U-11		
No password	Operator	Links to screen
R	R/W	
R	R	

Screen U-9
Review Operation
Alarm Active
Alarm Log
Unit Status/Settings
Circuit 1 Status/Settings
Circuit 2 Status/Settings
Scheduled Maintenance

From Screen U-1		
No password	Operator	Links to screen
		U-30
		U-31
		U-33
		Cx-2
		Cx-2
		U-8

U-10
Manual Control
Unit
Circuit 1
Circuit 2

From Screen U-1		
No password	Operator	Links to screen
		U-34
		Cx-3
		Cx-3

Screen U-11
Commission Unit
About This Chiller
Configuration
Set-Up
Date/Time/Schedules
Power Conservation
Alarm Limits
Calibrate Unit Sensors
Calibrate Circuit Sensors
LON Setup
BACnet IP Setup
BACnet MSTP Setup

From Screen U-1		
No password	Operator	Links to screen
		U-12
		U-23
		U-14
		U-16
		U-17
		U-26
		U-27
		U-35
		U-18
		U-19
		U-20

Continued next page.

Screen U-11
Commission Unit
Modbus Setup
AWM Setup
Ctrlr IP Setup
Alarm Active
Alarm Log
Scheduled Maintenance
Manual Control Unit
Manual Control Circuit 1
Manual Control Circuit 2

From Screen U-1		
No password	Operator	Links to screen
		U-21
		U-22
		U-24
		U-30
		U-31
		U-8
		U-34
		Cx-3
		Cx-3

Screen U-12
About Chiller
Model Number
G. O. Number
Unit Serial Number
BSP Version
Application Version
HMI GUID
OBH GUID

From Screen U-1, U11		
No password	Operator	Links to screen
R	R	
R	R	
R	R	
R	R	
R	R	
R	R	
R	R	

Screen U-13
Status/Settings
Unit Status
Next Compressor On
Next Compressor Off
Chiller Enable
Control Source
Chiller Enable Setpoint – Network
Chiller Mode Setpoint – Network
Cool Setpoint – Network
Capacity Limit Setpoint – Network
Stage Up Delay Remaining
Stage Down Delay Remaining
Clear Stage Delays
Ice Setpoint – Network
Ice Cycle Time Remaining
Clear Ice Cycle Delay
Evap Pump Control
Evap Recirculate Timer
Evap Nominal Delta T
Evap Pump 1 Run Hours
Evap Pump 2 Run Hours
Remote Service Enable

From Screen U-4		
No password	Operator	Links to screen
	R	
	R	
	R	
	R	
	R	
	R	
	R	
	R	
	R	
	R	
	R/W	
	R	
	R	
	R	
	R	
	R	

Continued next page.

Screen U-14

Set-Up
Available Modes
Start Up DT
Shut Down DT
Max Pulldown Rate
Stage Up Delay
Stage Down Delay
Start To Start Delay
Stop To Start Delay
Ice Cycle Delay
External Fault Config
Display Units

From Screen U-4, U11

No password	Operator	Links to screen
	R	
	R	
	R	
	R	
	R	
	R	

Screen U-15

Temperatures
Evap Leaving Water Temp
Evap Entering Water Temp
Evaporator Delta T
Active Set Point
Start Up Temperature
Shut Down Temperature
Stage Up Temperature
Stage Down Temperature
Pulldown Rate
Outside Air Temperature
Cool LWT Setpoint 1
Cool LWT Setpoint 2
Ice LWT Setpoint

From Screen U-4

No password	Operator	Links to screen
	R	
	R	
	R	
	R	
	R	
	R	
	R	
	R	
	R	
	R/W	
	R/W	
	R/W	

Screen U-16

Date/Time/Schedules
Actual Time
Actual Date
UTC Difference
DLS Enable
DLS Start Month
DLS Start Week
DLS End Month
DLS End Week

From Screen U-4, U-11

No password	Operator	Links to screen
	R/W	
	R/W	
	R/W	
	R/W	
	R/W	
	R/W	
	R/W	
	R/W	

Screen U-17

Power Conservation
Unit Capacity
Demand Limit Enable
Demand Limit Value
LWT Reset Enable

From Screen U-4, U-11

No password	Operator	Links to screen
	R	
	R/W	
	R	
	R/W	

Continued next page.

Screen U-18

LON Setup
Neuron ID
Max Send Time
Min Send Time
Receive Heartbeat
LON BSP
LON App Version

From Screen U-4, U-11

No password	Operator	Links to screen
	R	
	R/W	
	R/W	
	R/W	
	R	
	R	

Screen U-19

BACnet IP Setup
Apply Changes
Name
Dev Instance
UDP Port
DHCP
Actual IP Address
Actual Mask
Actual Gateway
Given IP Address
Given Mask
Given Gateway
Unit Support
NC Dev 1
NC Dev 2
BACnet BSP

From Screen U-4, U-11

No password	Operator	Links to screen
	R/W	
	R/W	
	R/W	
	R/W	
	R/W	
	R	
	R	
	R	
	R/W	
	R/W	
	R/W	
	R/W	
	R/W	
	R/W	
	R	

Screen U-20

BACnet MSTP Setup
Apply Changes
Name
Dev Instance
MSTP Address
Baud Rate
Max Master
Max Info Frm
Unit Support
Term Resistor
NC Dev 1
NC Dev 2
BACnet BSP

From Screen U-4, U-11

No password	Operator	Links to screen
	R/W	
	R/W	
	R/W	
	R/W	
	R/W	
	R/W	
	R/W	
	R/W	
	R/W	
	R/W	
	R/W	
	R/W	
	R	

Screen U-21

Modbus Setup
Apply Changes
Address
Parity
Two Stop Bits
Baud Rate
Load Resistor

From Screen U-4, U-11

No password	Operator	Links to screen
	R/W	
	R/W	
	R/W	
	R/W	
	R/W	
	R/W	

Continued next page.

Screen U-21

Modbus Setup
Response Delay
Comm LED Time Out
Modbus BSP

From Screen U-4, U-11

No password	Operator	Links to screen
	R/W	
	R/W	
	R	

Screen U-22

AWM Setup
Apply Changes
DHCP
Actual IP Address
Actual Mask
Actual Gateway
Given IP Address
Given Mask
Given Gateway
AWM BSP

From Screen U-4, U-11

No password	Operator	Links to screen
	R/W	
	R/W	
	R	
	R	
	R	
	R/W	
	R/W	
	R/W	
	R	

Screen U-23

Configuration
Apply Changes
Number Of Compressors
Expansion Valve Type
Number Of Fans
Fan VFD Enable
Power Configuration
Comm Module 1 Type
Comm Module 2 Type
Comm Module 3 Type

From Screen U-4, U-11

No password	Operator	Links to screen

Screen U-24

Ctrlr IP Setup
Apply Changes
DHCP
Actual IP Address
Actual Mask
Actual Gateway
Given IP Address
Given Mask
Given Gateway

From Screen U-4, U-11

No password	Operator	Links to screen
	R/W	
	R/W	
	R	
	R	
	R	
	R/W	
	R/W	
	R/W	

Screen U-25

Design Conditions
Evap Entering Water Temp @ Design
Evap Leaving Water Temp @ Design
Evap Design Water Flow
Evap Design Approach
Cond Design Ambient

From Screen U-4

No password	Operator	Links to screen
	R	
	R	
		*

Continued next page.

Screen U-25
Design Conditions
Screen U-25
Design Conditions
Cond Design Approach
Unit Full Load Efficiency
Unit Integrated Part Load Value
Rated Capacity

From Screen U-4		
No password	Operator	Links to screen
From Screen U-4		
No password	Operator	Links to screen
		*
	R	

Screen U-26
Alarm Limits
Low Pressure Hold Setpoint
Low Pressure Unload Setpoint
High Pressure Unload Setpoint
High Pressure Shutdown Setpoint
Low Ambient Start Time
Evaporator Water Freeze
Evaporator Flow Proof
Evap Recirculate Timeout

From Screen U-4, U-11		
No password	Operator	Links to screen
	R	
	R	

Screen U-27
Calibrate Sensors
Evap Leaving Water Temp
Evap LWT Offset
Evap Entering Water Temp
Evap EWT Offset
Outside Air Temp
OAT Offset

From Screen U-4, U-11		
No password	Operator	Links to screen

Screen U-28
Settings Change History
Change 1
Time/Date 1
Change 2
Time/Date 2
Change 3
Time/Date 3
Change 4
Time/Date 4
Change 5
Time/Date 5
Change 6
Time/Date 6

From Screen U-4		
No password	Operator	Links to screen

Screen U-29
Menu Password
Password Disable

From Screen U-4		
No password	Operator	Links to screen
	R	

Continued next page.

Screen U-30

Alarm Active
Active Count
Alarm Clear
Active Alarm 1
...
Active Alarm n

From Screen U-7, U-9, U-11

No password	Operator	Links to screen
R	R	
R/W	R/W	
R	R	
R	R	
R	R	

Screen U-31

Alarm Log
Log Count
Log Clear
Active Alarm 1
...
Active Alarm n

From Screen U-7, U-9, U-11

No password	Operator	Links to screen
R	R	
R	R	
R	R	
R	R	
R	R	

Screen U-32

Event Log
Unit Power Restore
Circuit #1
Circuit #2

From Screen U-7

No password	Operator	Links to screen
	R	U-36
	R	U-37
	R	U-38

Screen U-33

Unit Status/Settings
Actual Time
Actual Date
Unit Status
Unit Mode
Unit Capacity
Evap Leaving Water Temp
Evap Entering Water Temp
Active Set Point
Pulldown Rate
Outside Air Temperature

From Screen U-9

No password	Operator	Links to screen

Screen U-34

Unit Manual Control
Test Unit Alarm Out
Test Evap Pump 1 Out
Test Evap Pump 2 Out
Input/Output Values
Unit Switch Input State
PVM Input State
Evaporator Flow Switch State
Remote Switch Input State
External Alarm Input State
Double Set Point Input State
Evaporator LWT Input Resistance
Evaporator EWT Input Resistance
OAT Input Resistance

From Screen U-10, U-11

No password	Operator	Links to screen

Continued next page.

Screen U-34

Unit Manual Control
LWT Reset Signal Current
Demand Limit Signal Current
Unit Alarm Output State
Evaporator Pump 1 Output State
Evaporator Pump 2 Output State

From Screen U-10, U-11

No password	Operator	Links to screen

Screen U-35

Calibrate Circuit Sensors
Circuit #1
Circuit #2

From Screen U-11

No password	Operator	Links to screen
		Cx-8
		Cx-8

Screen U-36

Unit Power Restore Event Log
Day Selection
Count
Last Occurrence

From Screen U-32

No password	Operator	Links to screen
	R/W	
	R	
	R	

Screen U-37

Circuit 1 Event Log
Event Selection
Day Selection
Count
Last Occurrence

From Screen U-32

No password	Operator	Links to screen
	R/W	
	R/W	
	R	
	R	

Screen U-38

Circuit 1 Event Log
Event Selection
Day Selection
Count
Last Occurrence

From Screen U-32

No password	Operator	Links to screen
	R/W	
	R/W	
	R	
	R	

Screen Cx-1

View/Set Cirx
Data
Status/Settings
Comp 1/2
Comp 3/4
Comp 5/6
Condenser
EXV
Calibrate Sensors

From Screen U-5

No password	Operator	Links to screen
		Cx-4
	R	Cx-5
	R	Cmpx-1
	R	Cmpx-1
	R	Cmpx-1
		Cx-6
		Cx-7
		Cx-8

Screen Cx-2

Circuit x Status/Settings
Circuit Status
Circuit Mode
Circuit Capacity

From Screen U-9

No password	Operator	Links to screen
		*
		*
		*

Continued next page.

Screen Cx-2
Circuit x Status/Settings
Evap Leaving Water Temp
Evap Entering Water Temp
Evap Approach
Evap Approach @ Design
Evaporator Pressure
Evaporator Saturated Temperature
Condenser Pressure
Condenser Saturated Temperature
Suction Temperature
Suction Superheat
Compressor 1/2
Run Hours
Number Of Starts
Last Compressor Start
Last Compressor Stop
Compressor 3/4
Run Hours
Number Of Starts
Last Compressor Start
Last Compressor Stop
Compressor 5/6
Run Hours
Number Of Starts
Last Compressor Start
Last Compressor Stop
Condenser
Number of Fans Running
Stage Up Error
Stage Down Error
Condenser Target
VFD Target
VFD Speed
EXV
EXV State
EXV Position
Superheat Target
Suction Superheat
EXV Control Mode

From Screen U-9		
No password	Operator	Links to screen
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*

Screen Cx-3
Circuit x Manual Control
Test Comp 1/2 Output
Test Comp 3/4 Output
Test Comp 5/6 Output
Test Liquid Line Output
Test Hot Gas Output
Test EXV Position
Test Fan Output 1

From Screen U-10, U-11		
No password	Operator	Links to screen

Continued next page.

Downloaded from www.Manualslib.com manuals search engine

Screen Cx-3

Circuit x Manual Control
Test Fan Output 2
Test Fan Output 3
Test Fan Output 4
Test Fan Output 5
Test Fan VFD Speed
Input/Output Values
Circuit Switch Input State
MHP Switch Input State
Motor Protector Input State
PVM/GFP Input State
Evaporator Pressure Input Voltage
Condenser Pressure Input Voltage
Suction Temp Input Resistance
Compressor 1/2 Output State
Compressor 3/4 Output State
Compressor 5/6 Output State
Liquid Line Solenoid Output State
Hot Gas Bypass Output State
Fan Output 1 State
Fan Output 2 State
Fan Output 3 State
Fan Output 4 State
Fan Output 5 State
Fan VFD Speed

From Screen U-10, U-11

No password	Operator	Links to screen

Screen Cx-4

Data
Evaporator Pressure
Condenser Pressure
Saturated Evap Temperature
Saturated Cond Temperature
Suction Temperature
Suction Superheat
Evaporator Approach
Evaporator Design Approach
Condenser Approach
Condenser Design Approach
EXV Position
Evap Leaving Water Temp
Evap Entering Water Temp

From Screen Cx-1

No password	Operator	Links to screen
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*

Screen Cx-5

Status/Settings Cirx
Circuit Status
Circuit Mode
Circuit Capacity

From Screen Cx-1

No password	Operator	Links to screen
	R	*
	R	*
	R	*

Continued next page.

Screen Cx-6

Condenser
Number of Fans Running
Number of Fans
Stage Up Error
Stage Down Error
Condenser Sat Temp
Condenser Target
VFD Target
VFD Speed
Stage On Dead Band 1
Stage On Dead Band 2
Stage On Dead Band 3
Stage On Dead Band 4
Stage Off Dead Band 1
Stage Off Dead Band 2
Stage Off Dead Band 3
Stage Off Dead Band 4
VFD Max Speed
VFD Min Speed
Cond Target @ 100%
Cond Target @ 67%
Cond Target @ 50%
Cond Target @ 33%

From Screen Cx-1

No password	Operator	Links to screen
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*
		*

Screen Cx-7

EXV
EXV State
Suction Superheat
Superheat Target
EXV Control Mode
EXV Position
Evaporator Pressure
Max Evaporator Pressure

From Screen Cx-1

No password	Operator	Links to screen
		*
		*
		*
		*
		*
		*
		*

Screen Cx-8

Calibrate Sensors
Evaporator Pressure
Evap Pressure Offset
Condenser Pressure
Cond Pressure Offset
Suction Temp
Suction Temp Offset

From Screen Cx-1, U-35

No password	Operator	Links to screen

Screen Cmpx-1

Circuit x Comp x
Compressor State
Last Compressor Start
Last Compressor Stop
Run Hours
Number Of Starts

From Screen Cx-1

No password	Operator	Links to screen
		*
		*
		*
	R	*
	R	*

Optional Low Ambient Fan VFD

The optional VFD fan control is used for unit operation below 35°F (2°C) down to a minimum of -10°F (-23°C). The control looks at the saturated discharge temperature and varies the fan speed to hold the temperature (pressure) at the “target” temperature.

Low ambient air temperature control is accomplished by using the Optional Low Ambient VFD to control the speed of the first fan on each circuit. This VFD control uses a proportional integral function to drive the saturated condenser temperature to a target value by changing the fan speed. The target value is normally the same as the saturated condenser temperature target setpoint.

The fan VFD always starts when the saturated condenser temperature rises higher than the target.

What is an Inverter?

The term inverter and variable-frequency drive are related and somewhat interchangeable. An electronic motor drive, for an AC motor, controls the motor’s speed by varying the frequency of the power sent to the motor.


In general, an inverter is a device that converts DC power to AC power. The figure below shows how the variable-frequency drive employs an internal inverter. The drive first converts incoming AC power to DC through a rectifier bridge, creating an internal DC bus voltage. Then the inverter circuit converts the DC back to AC again to power the motor. The special inverter can vary its output frequency and voltage according to the desired motor speed.

Inverter Output to the Motor

⚠ WARNING

Avoid swapping any 2 of the 3 motor lead connections, which will cause reversal of the motor direction. In applications where reversed rotation could cause equipment damage or personnel injury, be sure to verify direction of rotation before attempting full-speed operation. For safety to personnel, the motor chassis ground must be connected to the ground connection at the bottom of the inverter housing.

The AC motor must be connected only to the inverter’s output terminals. The output terminals are uniquely labeled (to differentiate them from the input terminals) with the designations U/T1, V/T2, and W/T3. This corresponds to typical motor lead connection designations T1, T2, and T3. The consequence of swapping any two of the three connections is the reversal of the motor direction. This must not be done. In applications where reversed rotation could cause equipment damage or personnel injury, be sure to verify direction of rotation before attempting full-speed operation. For safety to personnel, the motor chassis ground must be connected to the ground connection at the bottom of the inverter housing.



Notice the three connections to the motor do not include one marked “Neutral” or “Return.” The motor represents a balanced “Y” impedance to the inverter, so there is no need for a separate return. In other words, each of the three “Hot” connections serves also as a return for the other connections because of their phase relationship.

Do not to switch off power to the inverter *while the motor is running* (unless it is an emergency stop) to avoid equipment damage. Also, do not install or use disconnect switches in the wiring from the inverter to the motor (except thermal disconnect).

VFD Interface (HMI)

The HMI is located in the lower left-hand corner of the unit control panel. It is used to view data including fault and alarm information. No operator intervention on this control is required for normal unit operation.




Table 15, Display Key Functions

No.	Display	Name	Function
1		Function Key(F1, F2)	The functions assigned to F1 and F2 vary depending on the currently displayed menu. The name of each function appears in the lower half of the display window.
2 3		ESC Key RESET Key	<ul style="list-style-type: none"> • Returns to the previous display. • Moves the cursor one space to the left. • Pressing and holding this button will return to the Frequency Reference display.
3			<ul style="list-style-type: none"> • Moves the cursor to the right. • Resets the drive to clear a fault situation.
4		RUN Key	Starts the drive in LOCAL mode.
5		Up Arrow Key	Scrolls up to display the next item, select parameter numbers, and increment setting values.
6		Down Arrow Key	Scrolls down to display the next item, select parameter numbers, and increment setting values.
7		STOP Key	Stops drive operation.
8		ENTER Key	<ul style="list-style-type: none"> • Enters parameter values and settings. • Selects a menu item to move between displays
9		LO/RE Selection Key	Switches drive control between the operator (LOCAL) and an external source (REMOTE) for the Run command and frequency reference.
10		RUN Light	Lit while the drive is operating the motor.
11		LO/RE Light	Lit while the operator is selected to run the drive (LOCAL mode).
12		ALM LED Light	Refer to ALARM (ALM) LED Displays on page 63

LCD Display




Table 16, Display Data

No	Name	Display	Content
1	Operation Mode Menus	MODE	Displayed when in Mode Selection.
		MONITR	Displayed when in Monitor Mode.
		VERIFY	Indicates the Verify Menu
		PRMSET	Displayed when in Parameter Setting Mode.
		A.TUNE	Displayed during Auto-Tuning.
		SETUP	Displayed when in Setup Mode.
2	DriveWorksEZ Function Selection	DWEZ	Displayed when DriveWorksEZ is set to enable. (A1-07 = 1 or 2)
3	Mode Display Area	DRV	Displayed when in Drive Mode.
		PRG	Displayed when in Programming Mode
4	Ready	Rdy	Indicates the drive is ready to run.
5	Data Display	—	Displays specific data and operation data.
6	Frequency Reference Assignment <1>	OPR	Displayed when the frequency reference is assigned to the LCD Operator Option.
		AI	Displayed when the frequency reference is assigned to the Analog Input of the drive
		COM	Displayed when the frequency reference is assigned to the MEMOBUS/Modbus CommunicationInputs of the drive
		OP	Displayed when the frequency reference is assigned to an Option Unit of the drive.
		RP	Displayed when the frequency reference is assigned to the Pulse Train Input of
7	LO/RE Display <2>	RSEQ	Displayed when the run command is supplied from a remote source.
		LSEQ	Displayed when the run command is supplied from the operator keypad.
		RREF	Displayed when the run command is supplied from a remote source.
		LREF	Displayed when the run command is supplied from the operator keypad
8	Function Key 1(F1)	JOG	Pressing [F1] executes the Jog function.
		HELP	Pressing [F1] displays the Help menu.
		←	Pressing [F1] scrolls the cursor to the left.
		HOME	Pressing [F1] returns to the top menu (Frequency Reference).
		ESC	Pressing [F1] returns to the previous display
9	FWD/REV	FWD	Indicates forward motor operation.
		REV	Indicates reverse motor operation.
10	Function Key 2 (F2)	FWD/REV	Pressing [F2] switches between forward and reverse
		DATA	Pressing [F2] scrolls to the next display
		→	Pressing [F2] scrolls the cursor to the right
		RESET	Pressing [F2] resets the existing drive fault error

Table 17, Alarm Content




State	Content	Display
Illuminated	When the drive detects an alarm or error	
Flashing	When an alarm occurs	
	When an oPE is detected	
	When a fault or error occurs during Auto-Tuning	
Off	Normal operation (no fault or alarm)	

Table 18, LO/RE LED and RUN LED Indicators











LED	Lit	Flashing Slowly	Flashing Quickly	Off
	When the operator is selected for Run command and frequency reference control (LOCAL)	--	--	When a device other than the operator is selected for Run command and frequency reference control (REMOTE)
	During run	<ul style="list-style-type: none"> • During deceleration to stop • When a Run command is input and frequency reference is 0 Hz 	<ul style="list-style-type: none"> • While the drive was set to LOCAL, a Run command was entered to the input terminals then the drive was switched to REMOTE. • A Run command was entered via the input terminals while the drive was not in the Drive Mode. • During deceleration when a Fast Stop command was entered. • The drive output is shut of by the Safe Disable function. • The STOP key was pressed while drive was running in REMOTE. • The drive was powered up with b1-17 = 0 (default) while the Run command was active. 	During stop
Examples				

Table 19, Types of Alarms, Faults, and Errors

Type	Drive Response
Faults	<p>When the drive detects a fault:</p> <ul style="list-style-type: none"> • The digital operator displays text indicating the specific fault and the ALM indicator LED remains lit until the fault is reset. • The fault interrupts drive output and the motor coasts to a stop. • Some faults allow the user to select the stopping method when the fault occurs. • Fault output terminals MA-MC will close, and MB-MC will open. <p>The drive will remain inoperable until the fault is cleared.</p>
Minor Faults and Alarms	<p>When the drive detects an alarm or a minor fault:</p> <ul style="list-style-type: none"> • The digital operator displays text indicating the specific alarm or minor fault, and the ALM indicator LED flashes. • The drive continues running the motor, although some alarms allow the user to select a stopping method when the alarm occurs. • A multi-function contact output set to be tripped by a minor fault (H2- □□ = 10) closes. If the output is set to be tripped by an alarm, the contact will not close. • The digital operator displays text indicating a specific alarm and the ALM indicator LED flashes. <p>Remove the cause of the problem to reset a minor fault or alarm.</p>
Operation Errors	<p>An operation error occurs when parameter settings conflict or do not match hardware settings (such as with an option card).When the drive detects an operation error:</p> <ul style="list-style-type: none"> • The digital operator displays text indicating the specific error. • Multi-function contact outputs do not operate. <p>The drive will not operate the motor until the error has been reset. Correct the settings that caused the operation error to clear the error.</p>
Tuning Errors	<p>Tuning errors occur while performing Auto-Tuning. When the drive detects a tuning error:</p> <ul style="list-style-type: none"> • The digital operator displays text indicating the specific error. • Multi-function contact outputs do not operate. • Motor coasts to stop. <p>Remove the cause of the error and repeat the Auto-Tuning process.</p>
Copy Function Errors	<p>Copy Function Errors occur when using the digital operator or the USB Copy Unit to copy, read, or verify parameter settings.</p> <ul style="list-style-type: none"> • The digital operator displays text indicating the specific error. • Multi-function contact outputs do not operate. <p>Pressing any key on the digital operator will clear the fault. Investigate the cause of the problem (such as model incompatibility)and try again.</p>

Table 20 Fault Reset Methods

NOTE: When a fault occurs, the cause of the fault must be removed and the drive must be restarted. The following tables list the various ways to restart the drive. Remove the Run command before attempting to clear a fault. If the Run command is present, the control will disregard any attempt to reset the fault

After the Fault Occurs	Procedure	
Fix the cause of the fault, restart the drive, and reset the fault	Press  on the HMI.	
Resetting via Fault Reset Digital Input S4	Close then open the fault signal digital input via terminal S4. S4 is set for "Fault Reset" as default (H1-04 = 14)	
Turn off the main power supply if the above methods do not reset the fault. Reapply power after the HMI display has turned off.		

Recommended Periodic Inspection

WARNING

Electrical Shock Hazard. Before servicing or inspection equipment, disconnect power to the unit. The internal capacitor remains charged after power is turned off. Wait at least the amount of time specified on the drive before touching any components.

Table 21, Periodic Inspection Checklist

Inspection Area	Inspection Points	Corrective Action
General	Inspect equipment including wiring, terminals, resistors, capacitors, diode and IGBT for discoloration from overheating or deterioration.	Replace damaged components.
	Inspect for dirt or foreign particles	Use dry air to clear away.
Relays and Contactors	Inspect contactors and relays for excessive noise.	Check for over or undervoltage
	Inspect for signs of overheating such as melted or cracked insulation	Replace damaged parts.

Optional BAS Interface

The AGZ chiller controller is configured for stand-alone operation or integration with BAS through an optional communication module.

The following installation manuals for optional BAS interface modules are shipped with the chiller. They can also be found and downloaded on www.DaikinApplied.com under Product Information > Air cooled Chillers> Scroll Type >Literature>Installation & Operation Manuals:

- IM 966-1, BACnet® IP Communication Module
- IM 967-1, BACnet® Communication Module (MS/TP)
- IM 968-1, LONWORKS Communication Module
- IM 969-2, Modbus® Communication Module
- ED 15120, Protocol Information for MicroTech III chiller, BACnet and LONWORKS
- ED 15121, Protocol Information for MicroTech III chiller, Modbus

Startup

Pre Start-up

The chiller must be inspected to ensure no components became loose or damaged during shipping or installation.

Start-Up

Refer to the MicroTech III Controller section beginning on page 13 to become familiar with its operation before starting chiller.

There should be adequate building load (at least 50 percent of the unit full load capacity) to properly check the operation of the chiller refrigerant circuits.

Be prepared to record all operating parameters required by the “Compressorized Equipment Warranty Form”. Return this information within 10 working days to Daikin Applied as instructed on the form to obtain full warranty benefits.

1. Verify chilled water flow.
2. Verify remote start / stop or time clock has requested the chiller to start.
3. Set the chilled water setpoint to the required temperature. (The system water temperature must be greater than the total of the leaving water temperature setpoint plus one-half the control band before the MicroTech III controller will stage on cooling).
4. Set the Evap Delta T and the Start Delta T as a starting point.
5. Put both pumpdown switches (PS1 and PS2) to the ON position.
6. Put system switch (S1) to ON position.

Switch	Switch Position	
	ON	OFF
PS1, PS2, Pumpdown Switches	Circuits will operate in the normal automatic mode	Circuit will go through the normal pumpdown cycle and shut off
S1, System Switch	Unit will operate in the normal automatic mode	Unit will shut off immediately without pumping down (emergency stop)

7. After the chiller has been operating for a period of time and has become stable, check the following:
 - Compressor oil level. (Some scroll compressors do not have oil sight glasses).
 - Refrigerant sight glass for flashing
 - Rotation of condenser fans
 - Complete the “Compressorized Equipment Warranty Form.”

Shutdown

Temporary

1. Put both circuit switches (PS1 and PS2) to the OFF position (Pumpdown and Stop).
2. After compressors have stopped, put System Switch (SW1) to OFF (emergency stop).
3. Turn off chilled water pump. Chilled water pump to operate while compressors are pumping down.

To start the chiller after a temporary shutdown, follow the start-up instructions.

Extended

1. Front seat (close) both condenser liquid line service valves.
2. Put both circuit switches (PS1 and PS2) to the OFF position (Pumpdown and Stop position).
3. After the compressors have stopped, put System Switch (SW1) to the OFF position (emergency stop).
4. Front seat both refrigerant circuit discharge valves (if applicable).
5. If chilled water system is not drained, maintain power to the evaporator heater to prevent freezing. Maintain heat tracing on the chilled water lines.
6. Drain evaporator and water piping to prevent freezing.
7. If electrical power to the unit is on, the compressor crankcase heaters will keep the liquid refrigerant out of the compressor oil. This will minimize start-up time when putting the unit back into service. The evaporator heater will be able to function.
8. If electrical power is off, make provisions to power the evaporator heater (if chilled water system is not drained or filled with correct anti-freeze). Tag all opened electrical disconnect switches to warn against start-up before the refrigerant valves are in the correct operating position.

To start the chiller after an extended shutdown, follow the prestart-up and start-up instructions.

Pre Startup Water Piping Checkout

1. Check the pump operation and vent all air from the system.
2. Circulate evaporator water, checking for proper system pressure and evaporator pressure drop. Compare the pressure drop to the evaporator water pressure drop curve.
3. Clean all water strainers before placing the chiller into service.

Pre Startup Refrigerant Piping Checkout

1. Check all exposed brazed joints for evidence of leaks. Joints may have been damaged during shipping or when the unit was installed.
2. Check that all refrigerant valves are either opened or closed as required for proper operation of the chiller.
3. A thorough leak test must be done using an approved electronic leak detector. Check all valve stem packing for leaks. Replace all refrigerant valve caps and tighten.
4. Check all refrigerant lines to insure that they will not vibrate against each other or against other chiller components and are properly supported.
5. Look for any signs of refrigerant leaks around the condenser coils and for damage during shipping or installation.
6. Leak detector fluid may be applied externally to refrigerant joints at the factory. Do not confuse this residue with an oil leak.
7. Connect refrigerant service gauges to each refrigerant circuit before starting unit.

Pre Startup Electrical Check Out

CAUTION

Electrical power must be applied to the compressor crankcase heaters 8 hours before starting unit to drive off refrigerant from the oil and prevent damage to the unit.

1. Open all electrical disconnects and check all power wiring connections. Start at the power block and check all connections through all components to and including the compressor terminals. These should be checked again after 3 months of operation and at least yearly thereafter.
2. Check all control wiring by pulling on the wire at the spade connections and tighten all screw connections. Check plug-in relays for proper seating and to insure retaining clips are installed.

3. Put System Switch (S1) to the Emergency Stop position.
4. Put both circuit #1 & #2 switches to the Pumpdown and Stop position.
5. Apply power to the unit. The panel Alarm Light will stay on until S1 is closed. Ignore the Alarm Light for the check out period. If you have the optional Alarm Bell, you may wish to disconnect it.
6. Check at the power block or disconnect for the proper voltage and proper voltage between phases. Check power for proper phasing using a phase sequence meter before starting unit.
7. Check for 120Vac at the optional control transformer and at TB-2 terminal #1 and the neutral block (NB).
8. Check between TB-2 terminal #7 and NB for 120 vac supply for transformer #2.
9. Check between TB-2 terminal #2 and NB for 120 vac control voltage. This supplies the compressor crank case heaters.
10. Check between TB-3 terminal #17 and #27 for 24 vac control voltage.

Operation

Hot Gas Bypass (Optional)

This option allows the system to operate at lower loads without excessive on/off compressor cycling. The hot gas bypass option is required to be on both refrigerant circuits because of the lead/lag feature of the controller.

This option allows passage of discharge gas into the evaporator inlet (between the TX valve and the evaporator) which generates a false load to supplement the actual chilled water or air handler load.

Note: The hot gas bypass valve cannot generate a 100% false load.

The pressure regulating valves are a Sporlan HGBE-8-75/150-7/8 ODF on models AGZ 025 to 065 and Sporlan HGBE-8-75/150-1 1/8 ODF on AGZ 070 to 190. They are factory set to begin opening at 100 psig (R-410A) and can be changed by changing the pressure setting. The adjustment range is 75 to 150 psig. To raise the pressure setting, remove the cap on the bulb and turn the adjustment screw clockwise. To lower the setting, turn the screw counterclockwise. Do not force the adjustment beyond the range it is designed for, as this will damage the adjustment assembly. The regulating valve opening point can be determined by slowly reducing the system load while observing the suction pressure. When the bypass valve starts to open, the refrigerant line on the evaporator side of the valve will begin to feel warm to the touch.

The bypass piping also includes a solenoid valve that is controlled by the MicroTech III controller. It is active when the first stage of cooling on a circuit is active.

WARNING

The hot gas line may become hot enough to cause injury. Be careful during valve checkout.

VFD Low Ambient Control (Optional)

The optional VFD fan control is used for unit operation below 35°F (2°C) down to a minimum of -10°F (-23.3°C). The control looks at the saturated discharge temperature and varies the fan speed to hold the temperature (pressure) at the “target” temperature. This temperature is established as an input to a setpoint screen labeled “Sat Condenser Temp Target”.

Compressor Communications

The communication module, installed in the 20 to 40 ton compressor electrical box, provides advanced diagnostics, protection, and communications that enhance compressor performance and reliability. Features include motor temperature protection, scroll temperature protection, missing phase protection, reverse phase protection, low control circuit voltage protection, short cycling detection and alert, modbus communication to system controller, operational and fault history storage, and LED status display.



OPERATION

Warnings and Alerts

A **solid green LED** indicates the module is powered and operation is normal.

A **solid red LED** indicates an internal problem with the module.

A **flashing green LED** communicates **Warning** codes. Warning codes do not result in a trip or lockout condition.

A **flashing red LED** communicates **Alert** codes. **Alert** codes will result in a trip condition and possibly a lockout condition

Warning Codes (Flashing Green LED)

Code 1 – Loss of Communication: The module will flash the green **Warning** LED one time indicating the module has not communicated with the master controller for longer than 5 minutes.

Code 2 – Reserved For Future Use

Code 3 – Short Cycling: The module will flash the green **Warning** LED three times indicating the compressor has short cycled more than 48 times in 24 hours.

Code 4 – Open/Shorted Scroll Thermistor: The module will flash the green **Warning** LED four times indicating an open/shorted

Alert/Lockout Codes (Flashing Red LED)

Code 1 – Motor High Temperature: The module will flash the red **Alert** LED one time indicating the motor is overheating . A code 1 **Alert** will open the M2-M1 contacts. The **Alert** will reset after 30 minutes. Five consecutive Code 1 **Alerts** will lockout the compressor. Once the module has locked out the compressor, a power cycle or Modbus reset command will be required for the lockout to be cleared.

Code 2 – Open/Shorted Motor Thermistor The module will flash the red **Alert** LED two times indicating the motor PTC thermistor circuit has an open/shorted thermistor chain (see **Table 2**). A Code 2 **Alert** will open the M2-M1 contacts. The **Alert** will reset after 30 minutes and the M2-M1 contacts will close if the resistance of the motor PTC circuit is back in the normal range. The module

will lockout the compressor and a power cycle or Modbus reset command will be required to clear the lockout.

Code 3 – Short Cycling: The module will flash the red **Alert** LED three times indicating the compressor is locked out due to short cycling. Once locked out the compressor, a power cycle or Modbus reset command will be required to clear the lockout.

Code 4 – Scroll High Temperature; The module will flash the red **Alert** LED four times indicating the over-temperature condition. A Code 4 **Alert** will open the M2-M1 contacts. The **Alert** will reset after 30 minutes. Once the module has locked out the compressor, a power cycle or Modbus reset command will be required to clear the lockout.

Code 5 – Reserved for Future Use

Code 6 – Missing Phase: The module will flash the red **Alert** LED six times indicating a missing phase. The **Alert** will reset after 5 minutes and the module will lockout the compressor after 10 consecutive Code 6 **Alerts**. Once locked out, a power cycle or Modbus reset is required.

Code 7 – Reverse Phase: The module will flash the red **Alert** LED seven times indicating a reverse phase in two of the three compressor leads. The modules will lockout the compressor after one Code 7 **Alert**. A power cycle or Modbus reset command will be required to clear the lockout.

Code 8 – Reserved For Future Use

Code 9 – Module Low Voltage; The module will flash the red **Alert** LED nine times indicating low module voltage for more than 5 seconds. . The **Alert** will reset after 5 minutes and the M2-M1 contacts will close if the T2-T1 voltage is above the reset value.

NOTE: If a compressor with CoreSense Communications fails in the field, the CoreSense module should remain with the failed compressor so the manufacturer's technicians can download the CoreSense data to assist with determining the root cause of compressor failure.

Filter-Driers

Each refrigerant circuit is furnished with a full flow filter drier (AGZ 030D – 100D) or a replaceable core type filter-drier (AGZ 140D – 180D). The core assembly of the replaceable core drier consists of a filter core held tightly in the shell in a manner that allows full flow without bypass.

Pressure drop across the filter drier at full load conditions must not exceed 10 psig at full load. See page for maximum pressure drop at other load points. Replace the filter drier if the pressure drop exceeds maximum.

WARNING

Pump out refrigerant before removing end flange for replacement of core(s) to remove liquid refrigerant and lower pressure to prevent accidental blow off of cover. EPA recovery regulations apply to this procedure.

A condenser liquid line service valve is provided for isolating the charge in the condenser, but also serves as the point from which the liquid line can be pumped out. With the line free of refrigerant, the filter-drier core(s) can be easily replaced.

System Adjustment

To maintain peak performance at full load operation, the system superheat and liquid subcooling may require adjustment. Read the following subsections closely to determine if adjustment is required.

Liquid Line Sight Glass

The color of the moisture indicator is an indication of the dryness of the system and is extremely important when the system has been serviced. Immediately after the system has been opened for service, the element may indicate a wet condition. It is recommended that the equipment operate for

about 12 hours to allow the system to reach equilibrium before deciding if the system requires a change of drier cores.

Bubbles in the sight glass at constant full load indicates a shortage of refrigerant, a plugged filter-drier, or a restriction in the liquid line. However, it is not unusual to see bubbles in the sight glass during changing load conditions.

Refrigerant Charging

Liquid line subcooling at the liquid shut-off valve should be between 15 and 20 degrees F at full load. If the unit is at steady full load operation and bubbles are visible in the sight glass, then check liquid subcooling.

Thermostatic Expansion Valve

The expansion valve performs one specific function. It keeps the evaporator supplied with the proper amount of refrigerant to satisfy the load conditions.

NOTE: Before adjusting superheat, check that unit charge is correct and liquid line sight glass is full with no bubbles and that the circuit is operating under stable, full load conditions.

The suction superheat for the suction leaving the evaporator is set at the factory for 8 to 12 degrees F at full load. To have full rated unit performance, the superheat must be about 8 degrees F at 95°F outdoor ambient temperature.

Crankcase Heaters

The scroll compressors are equipped with externally mounted band heaters located at the oil sump level. The function of the heater is to keep the temperature in the crankcase high enough to prevent refrigerant from migrating to the crankcase and condensing in the oil during off-cycle.

Power must be supplied to the heaters 8 hours before starting the compressors.

Evaporator

Models AGZ 025D through 130D

The evaporator is a compact, high efficiency, dual circuit, brazed, plate-to-plate type heat exchanger consisting of parallel stainless steel plates.

The evaporator is protected with an electric resistance heater and insulated with 3/4" (19mm) thick closed-cell polyurethane insulation. This combination provides freeze protection down to -20°F (-29°C) ambient air temperature.

The water side working pressure is 363 psig (2503 kPa). Evaporators are designed and constructed according to, and listed by, Underwriters Laboratories (UL).

NOTE: This product is equipped with a copper-brazed series 304 stainless steel plate evaporator. The water or other fluid used in these evaporators must be clean and non-corrosive to the materials used in the evaporator. The use of non-compatible fluids can void the equipment warranty. If the compatibility of the fluid with the evaporator is in question, a professional water quality consultant should administer the proper testing and evaluate compatibility.

Models AGZ 140D through 180D

The evaporator is direct expansion, shell-and-tube type with water flowing in the baffled shell side and refrigerant flowing through the tubes. Two independent refrigerant circuits within the evaporator serve the unit's dual refrigerant circuits.

The evaporator is wrapped with an electric resistance heater cable and insulated with 3/4" (19mm) thick vinyl nitrate polymer sheet insulation, protecting against water freeze-up at ambient air temperatures to -20°F (-29°C). An ambient air thermostat controls the heater cable. The fitted and glued-in-place insulation has a K factor of 0.28 Btu in/hr ft² °F at 75°F.

The refrigerant (tube) side maximum working pressure is 300 psig (2068 kPa). The water side working pressure is 152 psig (1048 kPa). Each evaporator is designed, constructed, inspected, and stamped according to the requirements of the ASME Boiler and Pressure Vessel Code. Double thickness insulation is available as an option.

Phase Voltage Monitor (Optional)

Factory settings are as follows:

- Trip Delay Time, 2 seconds
- Voltage Setting, set at nameplate voltage.
- Restart Delay Time, 60 seconds

Unit Maintenance

General

On initial start-up and periodically during operation, it will be necessary to perform certain routine service checks. Among these are checking the liquid line sight glasses, taking condensing and suction pressure readings, and checking to see that the unit has normal superheat and subcooling readings. A recommended maintenance schedule is located at the end of this section.

Compressor Maintenance

The scroll compressors are fully hermetic and require no maintenance other than checking oil level.

The compressors in this unit use POE lubricant. POE lubricant is required with refrigerant R-410A. Do not use mineral oil. See discussion of POE Lubricants in Service.

Electrical Terminals

DANGER

Electric shock hazard. Turn off all power before continuing with following service.

Condensers

The condensers are air-cooled and constructed of 3/8" (9.5mm) O.D. internally finned copper tubes bonded in a staggered pattern into louvered aluminum fins. Maintenance consists primarily of the routine removal of dirt and debris from the outside surface of the fins and repairing any fin damage. Daikin Applied recommends the use of foaming coil cleaners available at most air conditioning supply outlets. Use caution when applying such cleaners as they can contain potentially harmful chemicals. Care should be taken not to damage the fins during cleaning. The coils should be thoroughly rinsed to remove any cleaner residue.

If the service technician determines that the refrigerant circuit contains noncondensables,

recovery can be required, strictly following Clean Air Act regulations governing refrigerant discharge to the atmosphere. The Schrader purge valve is located on the vertical coil headers on both sides of the unit at the end opposite the control box. Decorative panels cover the condenser coils and must be removed for servicing. Recover with the unit off, after a shutdown of 15 minutes or longer, to allow air to collect at the top of the coil. Restart and run the unit for a brief period. If necessary, shut the unit off and repeat the procedure. Follow national and local regulations regarding refrigerant venting and reclamation when removing refrigerant from the unit.

The fan motor bearings are permanently lubricated and no further lubrication is required. Excessive fan motor bearing noise is an indication of a potential bearing failure.

Condensers with Electrofin® Coating

Documented routine quarterly coil cleaning of Electrofin coils is required to maintain the coating warranty. The cleaning procedure can be downloaded from the Electrofin web site www.luvata.com/electrofin, click on *Procedures for Cleaning*

Optional High Ambient Control Panel

Consists of exhaust fan with rain hood, two inlet screens with filters, necessary controls and wiring to allow operation to 125°F (52°C). The option can be factory or field installed as a kit.

- It must be supplied on units operating at ambient temperatures of 105°F (40.6°C) and above.
- It is automatically included on units with fan VFD (low ambient option).
- Check inlet filters periodically and clean as required. Verify that the fan is operational.

Liquid Line Sight Glass

The refrigerant sight glasses should be observed periodically (a weekly observation should be adequate.) A clear glass of liquid indicates that there is subcooled refrigerant charge in the system. Bubbling refrigerant in the sight glass, during stable run conditions, indicates that the system can be short of refrigerant charge. Refrigerant gas flashing in the sight glass could also indicate an excessive pressure drop in the liquid line, possibly due to a clogged filter-drier or a restriction elsewhere in the liquid line.

See Table 22 on page 77 for maximum allowable pressure drops. If subcooling is low,

add charge to clear the sight glass. If subcooling is normal (15 to 20 degrees F) and flashing is visible in the sight glass, check the pressure drop across the filter-drier. Subcooling should be checked at full load with 70°F (21.1°C) ambient temperature, stable conditions, and all fans running.

An element inside the sight glass indicates the moisture condition corresponding to a given element color. If the sight glass does not indicate a dry condition after about 12 hours of operation, the circuit should be pumped down and the filter-drier changed or verify moisture content by performing an acid test on the compressor oil.

Planned Maintenance Schedule

OPERATION	WEEKLY	MONTHLY (Note 1)	ANNUAL (Note 2)
General			
Complete unit log and review (Note 3)	X		
Visually inspect unit for loose or damaged components		X	
Inspect thermal insulation for integrity			X
Clean and paint as required			X
Electrical			
Check terminals for tightness, tighten as necessary			X
Clean control panel interior			X
Visually inspect components for signs of overheating		X	
Verify compressor heater operation		X	
Test and calibrate equipment protection and operating controls			X
Megger compressor motor *			X
Refrigeration			
Leak test		X	
Check sight glasses for clear flow	X		
Check filter-drier pressure drop (see manual for spec)		X	
Perform compressor vibration test			X
Acid test oil sample			X
Condenser (air-cooled)			
Clean condenser coils (Note 4)			X
Check fan blades for tightness on shaft (Note 5)			X
Check fans for loose rivets and cracks			X
Check coil fins for damage			X

Notes:

1. Monthly operations include all weekly operations.
2. Annual (or spring start-up) operations includes all weekly and monthly operations.
3. Log readings can be taken daily for a higher level of unit observation.
4. Coil cleaning can be required more frequently in areas with a high level of airborne particles.
5. Be sure fan motors are electrically locked out.

* Never Megger motors while they are in a vacuum to avoid damage to the motor.

Service

R-410A

Refrigerant Terminology

Bubble Point: The temperature/pressure where bubbles first appear when heat is added to a liquid refrigerant. Used to measure sub-cooling.

Dew Point: The temperature/pressure where droplets first appear when heat is removed from a refrigerant gas. Used to measure superheat.

Fractionalization: A change in refrigerant composition due to the tendency of the higher pressure refrigerant to leak at a faster rate, should a system have leakage from a static two-phase region.

Glide: The total difference of Dew and Bubble Point at a specific condition. Mid-Point or Mean: Measurement half way between Dew and Bubble Points.

Miscibility: The ability of a refrigerant and oil to mix and flow together.

Solubility: The effect of refrigerant on the viscosity of a lubricant.

Safety

Comparable to R-22; ANSI/ASHRAE safety group A1.

Always carry and be familiar with MSDS information for R-410a.

Store refrigerant in clean, dry area out of direct sunlight.

Never heat or store cylinders above 125° F. Note vehicle precautions!

Never tamper with cylinder valves or pressure relief valves. (Typical relief for R-410A is 525 psig).

Never refill disposable cylinders.

Verify cylinder hook-up.

Verify cylinder label and color code match. R-410A is rose/light maroon. Must be DOT approved, R-410A with 400 psig rating. Open cylinders slowly.

Avoid rough handling of cylinders and secure as appropriate. Cap when not in use.

Do not overfill recovery cylinders or overcharge units.

Check gauge calibration before every use and manifold set for leaks regularly.

Be aware of pneumatic and possible hydrostatic pressure potentials.

Never pressurize systems with oxygen or ref/air mix. R-410A, R-407C, R-134A, & R-22 are flammable with low air mix.

Wear protective clothing. Impervious gloves and splash goggles should be worn.

Avoid contact with liquid refrigerant (R-410A - 60.8°F @ atms.) due to corrosion and freezing hazards.

Avoid exposure to vapors. 1000 ppm/8 hr.

Evacuate areas in cases of large releases. R-410A is heavier than air and can cause asphyxiation, narcotic and cardiac sensation effects.

Evacuate systems and break vacuum (0 psig) with nitrogen before welding or brazing.

Always ventilate work areas before using open flames. Exposure to open flames or glowing metal will form toxic hydrofluoric acid & carbonyl fluoride. No smoking!

Make sure all tools, equipment, and replacement components are rated for the refrigerant used.

POE Lubricants

WARNING

POE oil must be handled carefully using proper protective equipment (gloves, eye protection, etc.) The oil must not come in contact with certain polymers (e.g. PVC), as it may absorb moisture from this material. Also, do not use oil or refrigerant additives in the system.

POE type oil is used for compressor lubrication. This type of oil is extremely hygroscopic which means it will quickly

absorb moisture if exposed to air and may form acids that can be harmful to the chiller. Avoid prolonged exposure of POE oil to the atmosphere to prevent this problem. For more details on acceptable oil types, contact your Daikin Applied service representative.

It is important that only the manufacturer's recommended oils be used. Acceptable POE oil types are:

- CPI/Lubrizol Emkarate RL32-3 MAF
- Exxon/Mobil EAL Arctic 22 CC*
- Hatcol 22CC*
- Everest 22CC*
- Copeland Ultra 32-3 MAF
- Parker Emkarate RL32-3MAF
- Virginia LE323MAF
- Nu Calgon 4314-66

Note - * These types of oils can only be used as "Top Off" oils. This is defined as adding less than 50% of the total amount of oil in the unit.

Pump the lubricant into the unit through a closed transfer system. Avoid overcharging the unit.

Use only new sealed metal containers of oil to insure quality.

Buy smaller containers to prevent waste and contamination.

Use only filter driers designed for POE and check pressure drops frequently.

Test for acid and color at least annually.

Change filter driers if acid or high moisture (> 200 ppm) is indicated (< 100 ppm typical).

Evacuate to 500 microns and hold test to insure systems are dry.

Control and Alarm Settings

The software that controls the operation of the unit is factory-set for operation with R-410A, taking into account that the pressure/temperature relationship differs from R-22. The software functionality is the same for either refrigerant.

Refrigerant Charging

The AGZ units have a condenser coil design with approximately 15% of the coil tubes located in a subcooler section of the coil to achieve liquid cooling to within 5°F (3°C) of the outdoor air temperature when all condenser fans are operating.

Once the subcooler is filled, extra charge will not lower the liquid temperature and does not help system capacity or efficiency.

If a unit is low on refrigerant, you must first determine the cause before attempting to recharge the unit. Locate and repair any refrigerant leaks. Soap works well to show bubbles at medium size leaks but electronic leak detectors are needed to locate small leaks.

Charging or check valves should always be used on charging hoses to limit refrigerant loss and prevent frostbite. Ball valve type recommended.

Charge to 80-85% of normal charge before starting the compressors.

Charging procedure. The units are factory-charged with R-410A. Use the following procedure if recharging in the field is necessary:

To prevent fractionalization, liquid must be charged from the refrigerant cylinder, unless charging the entire cylinder contents.

The charge can be added at any load condition between 25 to 100 percent load per circuit, but at least two fans per refrigerant circuit should be operating if possible.

Start the system and observe operation.

1. Trim the charge to the recommended liquid line sub-cooling (approximately 14-20 degrees F typical).
2. Verify the suction superheat (10 degrees F for EEVs and 10 – 12 degrees F for TXVs) at full load conditions.

Use standard charging procedures (liquid only) to top off the charge.

Check the sight glass to be sure there is no refrigerant flashing.

With outdoor temperatures above 60°F (15.6°C), all condenser fans should be operating and the liquid line temperature

should be within 5°F to 10°F (2.8°C to 5.6°C) of the outdoor air temperature. At 25-50% load, the liquid line temperature should be within 5°F (2.8°C) of outdoor air temperature with all fans on. At 75-100% load the liquid line temperature should be within 10°F (5.6°C) of outdoor air temperature with all fans on.

It may be necessary to add refrigerant through the compressor suction. Because the refrigerant leaving the cylinder must be a liquid, exercise care to avoid damage to the compressor by using a flow restrictor. A sight glass can be connected between the charging hose and the compressor. It can be adjusted to have liquid leave the cylinder and vapor enter the compressor.

Overcharging of refrigerant will raise the compressor discharge pressure due to filling of the condenser tubes with excess refrigerant.

Service

With R-410A, fractionalization, if due to leaks and recharge has a minimal effect on performance or operation.

Special tools will be required due to higher refrigerant pressures with R-410A. Oil-less/hp

recovery units, hp recovery cylinders (DOT approved w/525# relief), gauge manifold 30"-250 psi low/0-800 psi high, hoses w/800 psi working & 4,000 psi burst.

All filter driers and replacement components must be rated POE oils and for the refrigerant pressure (R-410A 600psig typical).

R-410A compressor internal relief is 600-650 psid.

Brazed connections only. No StayBrite or solder connections (solder should never be used with any refrigerant). K or L type refrigeration tubing only. Use nitrogen purge. Higher R-410A pressures and smaller molecule size make workmanship more critical.

R-410A must be charged from cylinder as a liquid unless entire cylinder is used. Use a Refrigerant flow restrictor if charging liquid to suction or to a system at pressure below a saturated temperature of 32° F.

EPA recovery and handling requirements for R-410A are the same as R-22.

Cooling the recovery cylinder will speed recovery and lessen stress on recovery equipment.

WARNING

Service on this equipment is to be performed by qualified refrigeration personnel familiar with equipment operation, maintenance, correct servicing procedures, and the safety hazards inherent in this work. Causes for repeated tripping of equipment protection controls must be investigated and corrected.

Disconnect all power before doing any service inside the unit.

Servicing this equipment must comply with the requirements set forth by the EPA in regards to refrigerant reclamation and venting.

Filter-Driers

Replace the filter-drier any time excessive pressure drop is read across the filter-drier and/or when bubbles occur in the sight glass with normal subcooling. The maximum recommended pressure drops across the filter-drier are shown below.

Table 22, Filter-Drier Pressure Drop

PERCENT CIRCUIT LOADING (%)	MAXIMUM RECOMMENDED PRESSURE DROP ACROSS FILTER DRIER PSIG (KPA)
100%	10 (69)
75%	8 (55.2)
50%	5 (34.5)
25%	4 (27.6)

The filter-drier should also be changed if the moisture indicating liquid line sight glass indicates excess moisture in the system.

During the first few months of operation the filter-drier replacement can be necessary if the pressure drop across the filter-drier exceeds the

Battery

The microprocessor has a battery located behind the clear plastic bezel. It is a BR2032 with a minimum life of 2 years unpowered. It would be prudent to replace it on a 2-year cycle. There is no indication of an eminent failure.

Liquid Line Solenoid Valve

The liquid line solenoid valves that shut off refrigerant flow in the event of a power failure do not normally require any maintenance. The solenoids can, however, require replacement of the solenoid coil or of the entire valve assembly.

Evaporator

The evaporators on AGZ-C models 030 - 130 are brazed plate type, and on models 140, 160, and 180 they are shell-and-tube type. Other than

values listed in the paragraph above. Any residual particles from the condenser tubing, compressor and miscellaneous components are swept by the refrigerant into the liquid line and are caught by the filter-drier.

The solenoid coil can be checked to see that the stem is magnetized when energized by touching a screwdriver to the top of the stem. If there is no magnetization, either the coil is bad or there is no power to the coil.

The solenoid coil can be removed from the valve body without opening the refrigerant piping after pumpdown. For personal safety, shut off and lock out the unit power.

The coil can then be removed from the valve body by simply removing a nut or snap-ring located at the top of the coil. The coil can then be slipped off its mounting stud for replacement.

To replace the entire solenoid valve follow the steps involved when changing a filter-drier.

cleaning and testing, no service work should be required on the evaporator.

AGZ-D Troubleshooting Chart

PROBLEM	POSSIBLE CAUSES	POSSIBLE CORRECTIVE STEPS
Compressor Will Not Run	<ol style="list-style-type: none"> 1. Main switch. 2. Fuse blown. circuit breakers open 3. Thermal overloads tripped 4. Defective contactor or coil. 5. System shutdown by equipment protection devices 6. No cooling required 7. Liquid line solenoid will not open 8. Motor electrical trouble 9. Loose wiring 	<ol style="list-style-type: none"> 1. Close switch. 2. Check electrical circuits and motor windings for shorts or grounds. Investigate for possible overloading. Replace fuse or reset breakers after fault is corrected. Check for loose or corroded connections. 3. Overloads are auto-reset. Check unit closely when unit comes back on line. Allow time for auto-reset. 4. Repair or replace 5. Determine type and cause of shutdown and correct it before resetting equipment protection switch. 6. None. Wait until unit calls for cooling. 7. Repair or replace solenoid coil. Check wiring. 8. Check motor for opens, shorts, or burnout. 9. Check all wire junctions. Tighten all terminal screws.
Compressor Noisy Or Vibrating	<ol style="list-style-type: none"> 1. Low or no refrigerant charge 2. Compressor running in reverse 3. Improper piping support on suction or discharge 4. Worn compressor isolator bushing 5. Worn Compressor 	<ol style="list-style-type: none"> 1. Repair and recharge 2. Check unit and compressor for correct phasing 3. Relocate, add, or remove hangers 4. Replace 5. Replace
High Discharge Pressure	<ol style="list-style-type: none"> 1. Noncondensables in system 2. System overcharged with refrigerant 3. Optional discharge shutoff valve partially closed 4. FanTrol wiring not correct 5. Fan not running 6. Dirty condenser coil 7. Air recirculation 	<ol style="list-style-type: none"> 1. Extract the noncondensables with approved procedures. 2. Remove excess, check liquid subcooling. 3. Open valve. 4. Check FanTrol wiring. 5. Check electrical circuit, Check fan motor. 6. Clean coil. 7. Correct.
Low Discharge Pressure	<ol style="list-style-type: none"> 1. Refrigerant flood back 2. Wind blowing into coil at low ambient 3. Faulty condenser temperature regulation 4. Insufficient refrigerant in system 5. Low suction pressure 6. Only one compressor operating 	<ol style="list-style-type: none"> 1. Correct. 2. Shield coil from direct wind, Wind guards are available. 3. Check condenser control operation. 4. Check for leaks. Repair and add charge. 5. See corrective steps for Low Suction Pressure. 6. See corrective steps for Compressor Will Not Stage Up.
High Suction Pressure	<ol style="list-style-type: none"> 1. Excessive water temperature 2. Excessive load 3. Expansion valve overfeeding 4. Compressors running in reverse 	<ol style="list-style-type: none"> 1. Check control settings. 2. Reduce load or add additional equipment. 3. Check remote bulb. Regulate superheat. 4. Check for proper phasing.
Low Suction Pressure	<ol style="list-style-type: none"> 1. Rapid load swings 2. Lack of refrigerant 3. Clogged liquid line filter drier 4. Expansion valve malfunctioning 5. Condensing temperature too low 6. Compressor will not unload 7. Insufficient water flow 8. Evaporator head ring gasket slippage 9. Evaporator dirty 10. Rapid load swings 	<ol style="list-style-type: none"> 1. Stabilize load. 2. Check for leaks, repair, add charge. Check liquid sight glass. 3. Check pressure drop across filter drier. Replace. 4. Check and reset for proper superheat. 5. Check means for regulating condenser temperature. 6. See corrective steps for Compressor Staging Intervals Too Low. 7. Adjust flow. 8. Take pressure drop across vessel and contact factory to obtain design pressure drop for that vessel. 9. Clean chemically. 10. Stabilize load.
Compressor Will Not Stage Up	<ol style="list-style-type: none"> 1. Defective capacity control 2. Faulty thermostat stage or broken wire 3. Stages not set for application 	<ol style="list-style-type: none"> 1. Replace. 2. Replace. 3. Reset thermostat setting for application.
Compressor Staging Intervals Too Short	<ol style="list-style-type: none"> 1. Thermostat control band not set properly 2. Faulty water temperature sensor 3. Insufficient water flow 4. Rapid load swings 	<ol style="list-style-type: none"> 1. Set control band wider. 2. Replace. 3. Adjust flow. 4. Stabilize load.

PROBLEM	POSSIBLE CAUSES	POSSIBLE CORRECTIVE STEPS
Compressor Oil Level Too High Or Too Low	<ol style="list-style-type: none"> 1. Oil hang-up in piping 2. Low oil level 3. Loose fitting on oil line 4. Level too high 5. Insufficient water flow - Level too high 6. Excessive liquid in crankcase - Level too high 7. Short cycling 	<ol style="list-style-type: none"> 1. Review refrigerant piping and correct. 2. Check and add oil. 3. Check and tighten system. 4. Adjust thermal expansion valve. 5. Adjust flow. 6. Check crankcase heater. Reset expansion valve for higher superheat. Check liquid line solenoid valve operation. 7. Stabilize load or increase staging interval.
Compressor Loses Oil	<ol style="list-style-type: none"> 1. Lack of refrigerant 2. Suction superheat too high 3. Crankcase heater burnout 	<ol style="list-style-type: none"> 1. Check for leaks and repair. Add refrigerant 2. Adjust superheat. 3. Replace crankcase heater.
Motor Overload Relays or Circuit Breakers Open	<ol style="list-style-type: none"> 1. Low voltage during high load conditions 2. Defective or grounded wiring in motor 3. Loose power wiring or burnt contactors 4. High condenser temperature 5. Power line fault causing unbalanced voltage 	<ol style="list-style-type: none"> 1. Check supply voltage for excessive line drop. 2. Replace compressor motor. 3. Check all connections and tighten. 4. See corrective steps for High Discharge Pressure. 5. Check supply voltage. Notify power company. Do not start until fault is corrected..
Compressor Thermal Protection Switch Open	<ol style="list-style-type: none"> 1. Operating beyond design conditions 2. Discharge valve partially shut 3. Blown compressor internal gasket 4. Voltage range or imbalance 5. High superheat 6. Compressor bearing failure 	<ol style="list-style-type: none"> 1. Add facilities so conditions are within allowable limits. 2. Open valve. 3. Replace gasket. 4. Check and correct. 5. Adjust to correct superheat. 6. Replace compressor .

Daikin Applied Training and Development

Now that you have made an investment in modern, efficient Daikin Applied equipment, its care should be a high priority. For training information on all Daikin Applied HVAC products, please visit us at www.DaikinApplied.com and click on Training, or call 540-248-9646 to speak with the Training Department.

Warranty

All Daikin Applied equipment is sold pursuant to its standard terms and conditions of sale, including Limited Product Warranty. Consult your local Daikin Applied sales representative for warranty details. To find your local Daikin Applied representative, go to www.DaikinApplied.com.

Aftermarket Services

To find your local parts office, visit www.DaikinApplied.com or call 800-37PARTS (800-377-2787). To find your local service office, visit www.DaikinApplied.com or call 800-432-1342.

This document contains the most current product information as of this printing. For the most up-to-date product information, please go to www.DaikinApplied.com.

